YAMAHA

PARTS CATALOGUE

MTN690 (BLW1) EUROPE

YAMAHA GENUINE Parts & Accessories

30BLW-300E1

( )

MTN690
PARTS CATALOGUE
©2025 by Yamaha Motor Co., Ltd.
1st edition, June 2025
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan.

FOREWORD

This Parts Catalogue is related to the parts for the model(s) on the cover page. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after the issue of the Parts Catalogue will be announced in the Parts News.
   It is advisable that you make the necessary corrections to the Parts Catalogue according to the Parts News.

2. Abbreviations
   The following abbreviations are used in this Parts Catalogue.
   "UR" Use specified parts number.
   "UN" Use as many as needed.
   "AP" Alternate Parts
   "LM" Locally Made (Parts need to be ordered locally)
   "F#" Frame No. (Applicable machine No.)
   "O/S" Over Size

3. The number of components for assembly
   - Parts, which are to be supplied in an assembly, are listed with a dot (.) in front of the part name as shown below.
   - The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

PART NO.	DESCRIPTION	Q'TY	REMARKS
2F5–83310–60	FRONT FLASHER LIGHT ASSY	2	
115–83311–60	.BULB (6V–18W)	1	

4. Applicable colours of graphics are represented in the "REMARKS" as shown below.


PART NO.	DESCRIPTION	Q'TY	REMARKS
2N4–24110–00–X5	FUEL TANK COMP.	2	MXR
3J1–24240–10	.GRAPHIC, FUEL TANK	1	FOR MXR

5. Note that the illustrations for reference in finding parts numbers are not to be used for assembling. When assembling, please use the applicable service manual.


6. The asterisk (*) before a reference number indicates modified items after the first edition.

7. Applicable Serial No.

Engine Serial No.



Frame Serial No.




8. Applicable Colour Code (The (*) mark shows Model colour.)

Abbreviation	Colour Name	Colour Code
BSC	BLUE SOLID C	1928
DPBM15	DEEP PURPLISH BLUE METALLIC 15	1329
DPBMC(*)	DEEP PURPLISH BLUE METALLIC C	0564
LGB	LOW GLOSS BLACK	0098
MBM3	MAT BLUE METALLIC 3	0960
MDNMD(*)	MAT DARK GRAY METALLIC D	1852
MLNM4(*)	MAT LIGHT GRAY METALLIC 4	1700


MODEL LABEL

(1) A label called “Model Label” is affixed in the location as indicated in (3) below.
When using this parts catalogue, please be sure to cross–reference the “model code – production code No.” in the catalogue with the “model code – production code No.” indicated on the Model Label affixed onto the product concerned.


(2) “Model Label” Indication



a: Model Type Code
b: Production Code No.
c: Colouring Type



(3) Model Label Affixing Location



(4) Colouring Information

Model Code	Colouring Type Code	Colour Code	Colour Name	Abbreviation
BLW1	A	0564	DEEP PURPLISH BLUE METALLIC C	DPBMC
	B	1700	MAT LIGHT GRAY METALLIC 4	MLNM4
	C	1852	MAT DARK GRAY METALLIC D	MDNMD

(5) Model Code – Production Code Number of Model Listed in This Parts Catalogue

Model Code	Production Code No.	Country (destination)
BLW1	010	ANDORRA
		AUSTRIA
		CZECHO
		ESTONIA
		FINLAND
		FRANCE
		GERMANY
		HUNGARY
		ITALY
		LIECHTENSTEIN
		LITHUANIA
		MONACO
		POLAND
		SLOVAK
		SPAIN
		SWITZERLAND
	050	ALBANIA
		BULGARIA
		CROATIA
		CYPRUS
		GREECE
		IRELAND
		ISRAEL
		ROMANIA
		SLOVENIA

Model Code	Production Code No.	Country (destination)
BLW1	050	TURKEY
		UKRAINE
	060	UNITED KINGDOM

CONTENTS

PERIODIC MAINTENANCE PARTS..... 1
MAINTENANCE PARTS KIT..... 2

ENGINE


CYLINDER HEAD..... 4
CRANKSHAFT & PISTON..... 5
VALVE..... 7
CAMSHAFT & CHAIN..... 9
WATER PUMP..... 10
RADIATOR & HOSE..... 12
OIL PUMP..... 14
OIL CLEANER..... 15
INTAKE..... 16
INTAKE 2..... 17
EXHAUST..... 18
CRANKCASE..... 19
CRANKCASE COVER 1..... 20
STARTER..... 21
CLUTCH..... 22
TRANSMISSION..... 24
SHIFT CAM & FORK..... 26
SHIFT SHAFT..... 27

CHASSIS

FRAME..... 28
FENDER..... 30
SIDE COVER..... 32
REAR ARM..... 34
REAR SUSPENSION..... 36
STEERING..... 37
FRONT FORK..... 38
FUEL TANK..... 40
FUEL TANK 2..... 42
SEAT..... 45
FRONT WHEEL..... 47
FRONT BRAKE CALIPER..... 48
REAR WHEEL..... 50
REAR BRAKE CALIPER..... 52
STEERING HANDLE & CABLE..... 53
FRONT MASTER CYLINDER..... 54
STAND & FOOTREST..... 55
STAND & FOOTREST 2..... 57
REAR MASTER CYLINDER..... 59
GENERATOR..... 61
STARTING MOTOR..... 62
FLASHER LIGHT..... 63
METER..... 64
HEADLIGHT..... 65
TAILLIGHT..... 67
HANDLE SWITCH & LEVER..... 68
ELECTRICAL 1..... 69
ELECTRICAL 2..... 71
ELECTRICAL 3..... 73

INDEX

NUMERICAL INDEX..... 74



BLW1300D0010

FIG. 1 PERIODIC MAINTENANCE PARTS

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	94701–00436	PLUG, SPARK (NGK LMAR8A-9)	1					
2	5GH–13440–90	ELEMENT ASSY, OIL CLEANER	1					
3	1WS–14450–00	ELEMENT ASSY, AIR CLEANER	1					
4	5SL–25805–00	BRAKE PAD KIT	2					
5	5VX–25806–00	BRAKE PAD KIT 2	1					
6	BLW–W001A–00	CHAIN & SPROCKET KIT	1					




FIG. 2 MAINTENANCE PARTS KIT

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–W001G–00	CLUTCH PLATE KIT	1					AP
2	BLW–15461–00	.GASKET, CRANKCASE COVER 2	1					
3	B7N–16321–00	.PLATE, FRICTION	4					
4	B90–16331–00	.PLATE, FRICTION 2	3					
5	5VY–16325–10	.PLATE, CLUTCH 2	3					(T2.0)
6	1TD–16324–00	.PLATE, CLUTCH 1	1					(T2.3)
7	BEB–16173–00	.SPRING, COMPRESSION	3					
8	4B1–16325–00	.PLATE, CLUTCH 2	1					UR (T2.3)
	BR9–16324–10	.PLATE, CLUTCH 1	1					UR (T1.6)
	5VY–16325–10	.PLATE, CLUTCH 2	1					UR (T2.0)
9	4B1–16325–00	.PLATE, CLUTCH 2	1					UR (T2.3)
	BR9–16324–10	.PLATE, CLUTCH 1	1					UR (T1.6)
	5VY–16325–10	.PLATE, CLUTCH 2	1					UR (T2.0)
10	BEB–W001M–00	FRICTION PLATE KIT	1					AP
11	B7N–16321–00	.PLATE, FRICTION	4					
12	B90–16331–00	.PLATE, FRICTION 2	3					
13	BBV–W003B–00	FORK SEALS KIT	1					AP
14	4EB–23144–00	.SEAL, DUST	1					
15	26H–23156–00	.RING, SNAP	1					
16	4EB–23145–01	.OIL SEAL	1					
17	1RC–23125–00	.METAL, SLIDE 1	1					
18	4FM–23171–40	.METAL, SLIDE	1					
19	509–23158–L0	.GASKET	1					(KYB)
20	39P–23147–00	.O-RING	1					
21	BVA–W000B–00	STEERING BEARING KIT	1					AP
22	93399–99932	.BEARING	1					
23	3FV–23462–00	.SEAL, STEERING	1					





FIG. 2 MAINTENANCE PARTS KIT


REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
24	93399–99931	.BEARING	1					
25	1W1–23416–00	.COVER, BALL RACE 2	1					
26	BLW–W001A–00	CHAIN & SPROCKET KIT	1					AP
27	BLW–17460–00	.SPROCKET, DRIVE (16T)	1					
28	90208–22002	.WASHER, CONICAL SPRING	1					
29	90179–22019	.NUT	1					
30	BLW–25443–00	.SPROCKET, DRIVEN (43T)	1					
31	94A40–24108	.SET, CHAIN (DID520VM5 108LE)	1					
32	94682–64021	..JOINT, CHAIN (DID520VM5 ZJ)	1					

FIG. 3 CYLINDER HEAD



BLW1300D0030


REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BAT–11101–09	CYLINDER HEAD ASSY	1					
2	4D9–11133–10	.GUIDE, VALVE 1	8					
3	91808–16023	.PIN, DOWEL	2					
4	91808–16023	.PIN, DOWEL	2					
5	90105–06027	.BOLT, FLANGE	12					
6	90340–18002	.PLUG, STRAIGHT SCREW	1					
7	93501–04011	.BALL	1					
8	90116–08087	.BOLT, STUD	4					
9	94701–00436	PLUG, SPARK (NGK LMAR8A-9)	2					
10	90109–06293	BOLT	1					
11	5VY–1111G–00	RUBBER, MOUNT 1	1					
12	90119–10056	BOLT, WITH WASHER	6					
13	90110–06081	BOLT, HEXAGON SOCKET HEAD	2					
14	BLW–11181–00	GASKET, CYLINDER HEAD 1	1					
15	99530–10114	PIN, DOWEL	2					
16	1WS–11190–10	COVER, CYLINDER HEAD 1	1					MDNM9
17	1WS–11165–01	.PLATE, BREATHER	1					
18	1WS–11169–00	.GASKET, BREATHER COVER	1					
19	90105–05024	.BOLT, FLANGE	6					
20	1WS–11193–01	.GASKET, HEAD COVER 1	1					
21	90109–066F0	BOLT	4					
22	5VY–1111G–00	RUBBER, MOUNT 1	4					



BLW1300D0040

FIG. 4 CRANKSHAFT & PISTON


REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–11400–00	CRANKSHAFT ASSY	1					
2	BLW–11650–00	CONNECTING ROD ASSY	2					
3	1RC–11654–00	.BOLT, CONNECTING ROD	2					
4	BME–11656–00	PLANE BEARING, CONNECTING ROD	4					UR BLUE
	BME–11656–10	PLANE BEARING, CONNECTING ROD	4					UR BLACK
	BME–11656–20	PLANE BEARING, CONNECTING ROD	4					UR BROWN
	BME–11656–30	PLANE BEARING, CONNECTING ROD	4					UR GREEN
5	BLW–11416–B0	PLANE BEARING, CRANKSHAFT 1	6					UR PURPLE
	BLW–11416–A0	PLANE BEARING, CRANKSHAFT 1	6					UR WHITE
	BLW–11416–00	PLANE BEARING, CRANKSHAFT 1	6					UR BLUE
	BLW–11416–10	PLANE BEARING, CRANKSHAFT 1	6					UR BLACK
	BLW–11416–20	PLANE BEARING, CRANKSHAFT 1	6					UR BROWN
6	1WS–11631–00	PISTON (STD)	2					
7	BLW–11603–00	PISTON RING SET (STD)	2					
8	1WS–11633–00	PIN, PISTON	2					
9	93450–19052	CIRCLIP	4					
10	90280–05029	KEY, WOODRUFF	1					
11	90105–12032	BOLT, FLANGE	1					
12	90201–12008	WASHER, PLATE	1					
13	BLW–11500–00	BALANCER ASSY	1					
14	1WS–11454–00	.WEIGHT 1	1					
15	1WS–11496–00	.BOSS, BUFFER	1					
16	1WS–11531–00	.GEAR, BALANCE WEIGHT	1					
17	90501–22721	.SPRING, COMPRESSION	8					
18	93605–10090	.PIN, DOWEL	4					
19	1WS–11533–00	.PLATE, ABSORBER	1					
20	90282–04036	.KEY, STRAIGHT	1					



BLW1300D0040

FIG. 4 CRANKSHAFT & PISTON


REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
21	90105–10445	.BOLT, FLANGE	1					
22	2S3–11413–00	METAL, BALANCE WEIGHT	6					UR BLUE
	2S3–11413–10	METAL, BALANCE WEIGHT	6					UR BLACK
	2S3–11413–20	METAL, BALANCE WEIGHT	6					UR BROWN
	2S3–11413–30	METAL, BALANCE WEIGHT	6					UR GREEN
	2S3–11413–40	METAL, BALANCE WEIGHT	6					UR YELLOW



BLW1300D0050

FIG. 5 VALVE


REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–12111–00	VALVE, INTAKE	4					
2	1WS–12121–01	VALVE, EXHAUST	4					
3	1WS–12113–01	SPRING, VALVE INNER	4					
4	1WS–12114–00	SPRING, VALVE OUTER	4					
5	1WS–12117–00	RETAINER, VALVE SPRING	8					
6	1WG–12118–00	LOCK, VALVE SPRING RETAINER	16					
7	4TE–12119–00	SEAL, VALVE STEM	8					
8	1WS–12116–00	SEAT, VALVE SPRING	8					
9	B4T–12153–00	LIFTER, VALVE	8					
	4C8–12153–09	LIFTER, VALVE (O/S)	8					AP GREEN
10	1HX–12168–F0	PAD, ADJUSTING 2 (1.50)	8					UR
	1HX–12168–H1	PAD, ADJUSTING 2 (1.55)	8					UR
	1HX–12168–K1	PAD, ADJUSTING 2 (1.60)	8					UR
	1HX–12168–M1	PAD, ADJUSTING 2 (1.65)	8					UR
	1HX–12168–R1	PAD, ADJUSTING 2 (1.70)	8					UR
	1HX–12168–U1	PAD, ADJUSTING 2 (1.75)	8					UR
	1HX–12168–W1	PAD, ADJUSTING 2 (1.80)	8					UR
	1HX–12168–Y1	PAD, ADJUSTING 2 (1.85)	8					UR
	1HX–12169–11	PAD, ADJUSTING 2 (1.90)	8					UR
	1HX–12169–31	PAD, ADJUSTING 2 (1.95)	8					UR
	1HX–12169–50	PAD, ADJUSTING 2 (2.00)	8					UR
	1HX–12169–70	PAD, ADJUSTING 2 (2.05)	8					UR
	1HX–12169–90	PAD, ADJUSTING 2 (2.10)	8					UR
	1HX–12169–E0	PAD, ADJUSTING 2 (2.15)	8					UR
	1HX–12169–G0	PAD, ADJUSTING 2 (2.20)	8					UR
	1HX–12169–J0	PAD, ADJUSTING 2 (2.25)	8					UR
	1HX–12169–L0	PAD, ADJUSTING 2 (2.30)	8					UR



BLW1300D0050

FIG. 5 VALVE

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
10	1HX–12169–N0	PAD, ADJUSTING 2 (2.35)	8					UR
	1HX–12169–T0	PAD, ADJUSTING 2 (2.40)	8					UR




BLW1300D0060

FIG. 6 CAMSHAFT & CHAIN

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–12170–00	CAMSHAFT ASSY 1	1					
2	BAT–12176–00	SPROCKET, CAM CHAIN	1					
3	90105–07006	BOLT, FLANGE	2					
4	1WS–12180–10	CAMSHAFT ASSY 2	1					
5	1WS–W1218–10	.CAMSHAFT SET	1					
6	1WS–12280–00	.DECOMPRESSION ASSY	1					
7	90105–07006	.BOLT, FLANGE	2					
8	1WS–12247–00	.SHAFT, TENSIONER	1					
9	1WS–12257–00	.SHAFT 2	1					
10	1PD–12288–00	.CAM, DECOMPRESSION	2					
11	94591–61134	CHAIN (T098XRH2015-134P)	1					
12	1WS–12210–02	TENSIONER ASSY, CAM CHAIN	1					
13	5EL–12228–00	.BOLT	1					
14	5SL–12214–00	.GASKET	1					
15	1WS–12213–00	GASKET, TENSIONER CASE	1					
16	90110–06396	BOLT, HEXAGON SOCKET HEAD	2					
17	1WS–12251–00	DAMPER, CHAIN 1	1					
18	1WS–12252–00	DAMPER, CHAIN 2	1					
19	90109–06295	BOLT	1					


FIG. 7 WATER PUMP



BLW1300D0070

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	1WS–12481–01	PIPE 1	1					
2	93210–235A1	O-RING	1					
3	1WS–12482–01	PIPE 2	1					
4	95022–06010	.BOLT, FLANGE	1					
5	90430–06014	.GASKET	1					
6	93210–235A1	O-RING	1					
7	91314–06014	BOLT, HEXAGON SOCKET HEAD	1					
8	90110–06152	BOLT, HEXAGON SOCKET HEAD	1					
9	1WS–12576–00	HOSE 1	1					
10	1WS–12576–00	HOSE 1	1					
11	90467–290A0	CLIP	2					
12	90450–35001	HOSE CLAMP ASSY	1					
13	90467–290A0	CLIP	1					
14	1WS–12469–00	JOINT 1	1					
15	93210–33006	O-RING	1					
16	95812–06020	BOLT, FLANGE	2					
17	1WS–12410–01	THERMOSTAT ASSY	1					
18	BLW–12413–00	COVER, THERMOSTAT	1					
19	95817–06020	BOLT, FLANGE	2					
20	1WS–12588–01	HOSE 5	1					
21	90467–170A6	CLIP	2					
22	1WS–12589–01	HOSE 6	1					
23	90467–170A6	CLIP	2					
24	BLW–12420–00	WATER PUMP ASSY	1					
25	1WS–12450–00	.IMPELLER SHAFT ASSY	1					
26	93306–00106	.BEARING	1					
27	5VK–12438–00	.SEAL, MECHANICAL	1					


FIG. 7 WATER PUMP



BLW1300D0070


REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
28	2CR–13338–00	.SEAL	1					
29	99009–12400	.CIRCLIP	1					
30	1WS–12422–10	.COVER, HOUSING	1					MDNM9
31	1WS–12439–00	.O-RING	1					
32	93603–12007	.PIN, DOWEL	1					
33	90110–06295	.BOLT, HEXAGON SOCKET HEAD	3					
34	BLW–15421–00	.COVER, CRANKCASE 2	1					
35	2D1–16382–00	.AXLE, PUSH LEVER	1					
36	92907–08600	.WASHER, PLATE	1					
37	99001–07600	.CIRCLIP	1					
38	93317–11096	.BEARING	1					
39	93315–21570	.BEARING	1					
40	93102–15212	.OIL SEAL	1					

FIG. 8 RADIATOR & HOSE



REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–12461–00	RADIATOR COMP	1					
2	BEB–12405–00	BLOWER ASSY	1					
3	1WS–12671–00	NUT 1	2					
4	2S3–12675–00	BOLT, BLOWER HOLDING	3					
5	1WS–12671–00	NUT 1	4					
6	90480–15363	GROMMET	3					
7	90387–06263	COLLAR	1					
8	95D32–06025	BOLT, FLANGE DEEP RECESS	1					
9	5SL–12462–01	CAP, RADIATOR	1					
10	1WS–12578–00	HOSE 3	1					
11	90467–290A0	CLIP	1					
12	90450–35001	HOSE CLAMP ASSY	1					
13	BLW–21871–00	TANK, RECOVERY	1					
14	26H–21828–00	ELBOW	1					
15	BEB–21817–00	PIPE 2	1					
16	3P6–21875–00	CAP	1					
17	BEB–21816–00	PIPE 1	1					
18	4XY–14568–00	JOINT	1					
19	BLW–2172W–00	COVER	1					
20	90269–06008	RIVET	1					
21	90387–06024	COLLAR	1					
22	90110–06163	BOLT, HEXAGON SOCKET HEAD	1					
23	90445–10064	HOSE	1					
24	90464–07M40	CLAMP	1					
25	BLW–21731–00	COVER, SIDE 3	1					
26	B7N–83321–00	DAMPER, FLASHER 1	1					
27	90111–06191	BOLT, HEXAGON SOCKET BUTTON	2					


FIG. 8 RADIATOR & HOSE



BLW1300D0080

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
28	BLW–21741–00	COVER, SIDE 4	1					
29	B7N–83321–00	DAMPER, FLASHER 1	1					
30	90111–06191	BOLT, HEXAGON SOCKET BUTTON	2					
31	BLW–2172A–00	PANEL 1	1					
32	97707–50016	SCREW, TRUSS HEAD TAPPING	2					
33	90183–05042	NUT, SPRING	2					


FIG. 9 OIL PUMP



BLW1300D0090

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–13300–00	OIL PUMP ASSY	1					
2	99009–15500	.CIRCLIP	1					
3	95812–06040	BOLT, FLANGE	4					
4	94581–79060	CHAIN (DID25H-60LE)	1					
5	90110–06168	BOLT, HEXAGON SOCKET HEAD	1					
6	1WS–13410–00	STRAINER HOUSING ASSY	1					
7	93210–207A0	O-RING	1					
8	90480–13010	GROMMET	1					
9	5VY–13117–10	COLLAR, DISTANCE	1					
10	90110–06173	BOLT, HEXAGON SOCKET HEAD	3					


FIG. 10 OIL CLEANER



BLW1300D0100

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	1WS–13470–00	OIL COOLER ASSY	1					
2	1XD–13475–00	GASKET	1					
3	BBW–12858–00	BOLT, UNION	1					
4	5GH–13440–90	ELEMENT ASSY, OIL CLEANER	1					
5	BLW–13417–00	COVER, STRAINER	1					
6	90340–14132	PLUG, STRAIGHT SCREW	1					
7	214–11198–01	GASKET	1					
8	BLW–13414–00	GASKET, STRAINER COVER	1					
9	91312–06030	BOLT, HEXAGON SOCKET HEAD	11					


FIG. 11 INTAKE



BLW1300D0110

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	1WS–13635–00	JOINT, INTAKE 1	2					
2	90450–56011	HOSE CLAMP ASSY	2					
3	90450–56012	HOSE CLAMP ASSY	2					
4	BLW–13542–00	HOSE, VACUUM SENSING 1	1					
5	BLW–14401–00	AIR CLEANER CASE ASSY	1					
6	BLW–14417–00	.COVER 1	1					
7	1RC–2111D–00	.SEAL 1	2					
8	BLW–14418–00	.COVER 2	1					
9	1RC–2111D–00	.SEAL 1	2					
10	1WS–14450–00	ELEMENT ASSY, AIR CLEANER	1					
11	1WS–14452–00	.SEAL	1					
12	BLW–14469–00	FUNNEL, AIR	1					
13	BLW–1446C–00	FUNNEL 2	1					
14	90160–05013	SCREW, ROUND TAPPING	5					
15	BLW–14437–00	DUCT	1					
16	90450–56012	HOSE CLAMP ASSY	1					
17	90450–56011	HOSE CLAMP ASSY	1					
18	1WS–1443E–00	PIPE, DRAIN	1					
19	90467–13083	CLIP	1					
20	90480–15001	GROMMET	1					
21	90480–15014	GROMMET	1					
22	90387–06300	COLLAR	2					
23	95817–06025	BOLT, FLANGE	2					
24	90201–064K6	WASHER, PLATE	1					
25	BLW–11166–00	PIPE, BREATHER 1	1					
26	90467–17128	CLIP	1					
27	90467–160A2	CLIP	1					


FIG. 12 INTAKE 2





BLW1300D0120

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–13750–00	THROTTLE BODY ASSY	1					
2	8FP–13556–00	.RUBBER, INJECTOR	2					
3	1WS–13761–00	.INJECTOR	2					
4	5PS–14147–00	..O-RING	1					
5	8CC–14216–10	.SCREW	2					
6	B7M–85885–01	.THROTTLE SENSOR ASSY	1					
7	14B–13573–00	.BOLT 1	2					
8	363–14198–00	.GASKET	2					
9	14B–14466–00	.PIPE	1					
10	90413–06031	.WAY 3	1					
11	90467–090A2	.CLIP	4					
12	1WS–14465–00	.PIPE	1					
13	895–14169–00	.CAP	1					
14	8A7–14139–00	.CLIP, PIPE	1					
15	2C0–14105–00	.PILOT SCREW SET	2					



BLW1300D0130

FIG. 13 EXHAUST

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–14703–00	MUFFLER COMP. 1	1					
2	BLW–14708–00	PROTECTOR ASSY	1					
3	90111–06194	BOLT, HEXAGON SOCKET BUTTON	3					
4	B4T–8592A–00	SENSOR, OXYGEN	1					
5	BGM–H592A–10	SENSOR, OXYGEN	1					
6	3YF–14613–01	GASKET, EXHAUST PIPE	2					
7	90179–08410	NUT	4					
8	20S–21445–01	STAY, MUFFLER 1	2					
9	90105–08164	BOLT, FLANGE	2					
10	95D34–06016	BOLT, FLANGE DEEP RECESS	4					
11	B4T–14628–10	PROTECTOR, EXHAUST PIPE	1					
12	90111–06194	BOLT, HEXAGON SOCKET BUTTON	2					






FIG. 14 CRANKCASE

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–15100–09	CRANKCASE ASSY	1					
2	5EB–15155–00	.NOZZLE 3	2					
3	93210–04092	.O-RING	2					
4	99530–10014	.PIN, DOWEL	3					
5	BME–15189–00	.PLUG	3					
6	93210–12790	.O-RING	3					
7	2H7–15361–00	GAUGE, LEVEL	1					
8	36Y–15189–01	PLUG	1					
9	93210–16325	O-RING	1					
10	90119–09018	BOLT, WITH WASHER	6					(M9X1.25 - 90mm)
11	1WS–15156–00	BOLT, CRANKCASE JOURNAL	6					
12	93210–07540	.O-RING	1					
13	95812–08065	BOLT, FLANGE	2					
14	95812–06040	BOLT, FLANGE	8					
15	95812–06060	BOLT, FLANGE	3					
16	90109–06100	BOLT	2					
17	90462–08102	CLAMP	1					
18	1WS–15416–10	COVER, OIL PUMP	1					MDNM9
19	BLW–15456–00	GASKET, OIL PUMP COVER 1	1					
20	90110–06395	BOLT, HEXAGON SOCKET HEAD	2					
21	BLW–15128–00	HOLDER	1					

FIG. 15 CRANKCASE COVER 1



REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–15411–00	COVER, CRANKCASE 1	1					
2	99480–03014	PIN	1					
3	90340–36008	PLUG, STRAIGHT SCREW	1					
4	93210–357A3	O-RING	1					
5	92017–08012	BOLT, BUTTON HEAD	1					
6	90430–08143	GASKET	1					
7	BLW–15451–00	GASKET, CRANKCASE COVER 1	1					
8	99530–08012	PIN, DOWEL	2					
9	90110–06388	BOLT, HEXAGON SOCKET HEAD	8					
10	90110–06389	BOLT, HEXAGON SOCKET HEAD	2					
11	BLW–15418–00	COVER, CHAIN CASE	1					
12	BLW–15377–00	GUIDE, INLET	1					
13	90110–06396	BOLT, HEXAGON SOCKET HEAD	3					
14	99530–08012	PIN, DOWEL	2					
15	90110–06388	BOLT, HEXAGON SOCKET HEAD	10					
16	BLW–15484–00	CLAMP 2	2					
17	BLW–15441–00	HOLDER, CLUTCH CABLE	1					
18	90110–06389	BOLT, HEXAGON SOCKET HEAD	2					
19	BAT–15362–00	PLUG, OIL LEVEL	1					
20	93210–27194	O-RING	1					
21	B5Y–1548B–00	OIL, LABEL	1					




BLW1300D0160

FIG. 16 STARTER


REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–15515–00	GEAR 3	1					
2	1WS–15590–00	STARTER ONE-WAY ASSY	1					
3	90149–08030	SCREW	3					
4	23P–15521–00	SHAFT 1	2					
5	1WS–15512–00	GEAR, IDLER 1	1					
6	BLW–15517–00	GEAR, IDLER 2	1					

FIG. 17 CLUTCH




REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	1WS–16150–00	PRIMARY DRIVEN GEAR COMP.	1					
2	363–16154–00	PLATE, THRUST 1	1					
3	BEB–16371–00	BOSS, CLUTCH	1					
4	B7N–16321–00	PLATE, FRICTION	4					
5	B90–16331–00	PLATE, FRICTION 2	3					
6	5VY–16325–10	PLATE, CLUTCH 2	3					(T2.0)
7	1TD–16324–00	PLATE, CLUTCH 1	1					(T2.3)
8	BEB–16350–00	PRESSURE PLATE ASSY	1					
9	BEB–16173–00	SPRING, COMPRESSION	3					
10	B90–16352–00	PLATE, PRESSURE 2	1					
11	2CR–16337–00	SCREW, SPRING	3					
12	1TD–16383–01	SPRING.,CUSHION	1					
13	1TD–16384–00	PLATE, SEAT	1					
14	4B1–16325–00	PLATE, CLUTCH 2	1					UR (T2.3)
	BR9–16324–10	PLATE, CLUTCH 1	1					UR (T1.6)
	5VY–16325–10	PLATE, CLUTCH 2	1					UR (T2.0)
15	4B1–16325–00	PLATE, CLUTCH 2	1					UR (T2.3)
	BR9–16324–10	PLATE, CLUTCH 1	1					UR (T1.6)
	5VY–16325–10	PLATE, CLUTCH 2	1					UR (T2.0)
16	1WS–16181–00	SPACER 1	1					
17	93310–332C2	BEARING	1					
18	363–16154–00	PLATE, THRUST 1	1					
19	90201–20030	WASHER, PLATE	1					
20	90208–20001	WASHER, CONICAL SPRING	1					
21	90179–20022	NUT	1					
22	1WS–16356–00	ROD, PUSH 1	1					
23	1WS–16340–01	PUSH LEVER ASSY	1					

FIG. 17 CLUTCH




REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
24	90508–18132	SPRING, TORSION	1					
25	90201–10029	WASHER, PLATE	1					
26	99009–10400	CIRCLIP	1					
27	BLW–15461–00	GASKET, CRANKCASE COVER 2	1					
28	BLW–W001G–00	CLUTCH PLATE KIT	1					AP
29	BEB–W001M–00	FRICTION PLATE KIT	1					AP



BLW1300D0180

FIG. 18 TRANSMISSION

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–17401–00	MAIN AXLE ASSY	1					
2	BLW–17151–00	GEAR, 5TH PINION (22T)	1					
3	90387–25043	COLLAR	1					
4	90209–21332	WASHER	1					
5	93440–25186	CIRCLIP	1					
6	1WS–17131–00	GEAR, 3RD PINION (20T/19T)	1					
7	93440–25186	CIRCLIP	1					
8	90209–21332	WASHER	1					
9	BLW–17161–00	GEAR, 6TH PINION (28T)	1					
10	90387–21003	COLLAR	1					
11	90209–22352	WASHER	1					
12	90209–21351	WASHER	1					
13	1WS–17121–00	GEAR, 2ND PINION (16T)	1					
14	93306–20464	BEARING	1					
15	1WS–17446–00	PLATE	1					
16	90149–06189	SCREW	3					
17	1WS–17421–00	AXLE, DRIVE	1					
18	93306–20663	BEARING	1					
19	90387–30012	COLLAR	1					
20	93440–64199	CIRCLIP	1					
21	93102–40030	OIL SEAL	1					
22	BLW–17221–00	GEAR, 2ND WHEEL (34T)	1					
23	90387–31003	COLLAR	1					
24	90209–28008	WASHER	1					
25	93440–31187	CIRCLIP	1					
26	BLW–17261–00	GEAR, 6TH WHEEL (27T)	1					
27	93440–31187	CIRCLIP	1					




BLW1300D0180

FIG. 18 TRANSMISSION


REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
28	90209–28008	WASHER	1					
29	1WS–17241–00	GEAR, 4TH WHEEL (26T)	1					
30	90387–28004	COLLAR	1					
31	90214–29002	WASHER, CLAW	1					
32	90214–28002	WASHER, CLAW	1					
33	BLW–17231–00	GEAR, 3RD WHEEL (31T)	1					
34	90387–28004	COLLAR	1					
35	90209–28008	WASHER	1					
36	93440–31187	CIRCLIP	1					
37	BLW–17251–00	GEAR, 5TH WHEEL (24T)	1					
38	BLW–17211–00	GEAR, 1ST WHEEL (37T)	1					
39	90387–25008	COLLAR	1					
40	90201–20008	WASHER, PLATE	1					
41	93306–20464	BEARING	1					

FIG. 19 SHIFT CAM & FORK



BLW1300D0190

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–18540–00	SHIFT CAM ASSY	1					
2	1WS–18511–00	FORK, SHIFT 1	1					
3	1WS–18512–00	FORK, SHIFT 2	1					
4	1WS–18513–00	FORK, SHIFT 3	1					
5	20S–18535–00	BAR, SHIFT FORK GUIDE 2	2					
6	1WS–18536–00	STOPPER, SHIFT BAR	1					
7	90149–06158	SCREW	2					




BLW1300D0200

FIG. 20 SHIFT SHAFT

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	90506–18021	SPRING, TENSION	1					
2	132–16346–00	HOOK, SPRING	1					
3	1D7–18127–00	STOPPER, SCREW	1					
4	1WS–18101–00	SHIFT SHAFT ASSY	1					
5	90508–29040	.SPRING, TORSION	1					
6	2C0–18175–00	.SPACER	1					
7	1WS–18140–00	.STOPPER LEVER ASSY	1					
8	90201–177G4	.WASHER, PLATE	1					
9	99009–17400	.CIRCLIP	1					
10	93317–11295	BEARING	1					
11	93102–12106	OIL SEAL (SD 12-22-5 HS)	1					
12	90201–12575	WASHER, PLATE	2					
13	99002–10600	CIRCLIP	1					
14	BLW–18112–00	ARM, SHIFT	1					
15	91317–06020	BOLT, HEXAGON SOCKET HEAD	1					


FIG. 21 FRAME



BLW1300D0210


REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–21110–10	FRAME COMP.	1					
2	1WS–2191B–00	PLATE 1	1					
3	90105–10219	BOLT, FLANGE	1					
4	90105–10349	BOLT, FLANGE	1					
5	90179–10024	NUT	2					
6	90201–10035	WASHER, PLATE	2					
7	90105–12092	BOLT, FLANGE	2					
8	90201–13020	WASHER, PLATE	2					
9	BLW–21315–00	STAY, ENGINE 1	1					
10	BLW–21316–00	STAY, ENGINE 2	1					
11	90110–10044	BOLT, HEXAGON SOCKET HEAD	2					
12	90110–08111	BOLT, HEXAGON SOCKET HEAD	4					
13	90480–01559	GROMMET	2					
14	90520–20022	DAMPER, PLATE	1					
15	BLW–21596–00	HOLDER	1					
16	95027–06014	BOLT, FLANGE	1					
17	90387–06173	COLLAR	1					
18	90109–06043	BOLT	1					
19	90109–06172	BOLT	1					
20	90183–060A6	NUT, SPRING	2					
21	95027–06014	BOLT, FLANGE	2					
22	1WS–2161J–00	BRACKET 8	1					
23	92012–06010	BOLT, BUTTON HEAD	1					
24	BLW–2175U–00	BRACKET 2	1					
25	90269–07077	RIVET	1					
26	BLW–2115L–00	BRACKET, MEMBER 1	1					
27	92012–06016	BOLT, BUTTON HEAD	4					

FIG. 21 FRAME



BLW1300D0210

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
28	BLW–21288–00	GUIDE, CABLE	1					
29	95027–06010	BOLT, FLANGE	1					
30	BLW–2141G–00	BRKT., 4	1					
31	92012–06016	BOLT, BUTTON HEAD	2					
32	3HA–24141–00	PROTECTOR, FUEL TANK	1					




BLW1300D0220

FIG. 22 FENDER

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–21511–00–P0	FENDER, FRONT	1					MBM3 FOR DPBMC
	BLW–21511–00–P1	FENDER, FRONT	1					FOR MLNM4
	BLW–21511–00–P2	FENDER, FRONT	1					FOR MDNMD
2	90111–06191	BOLT, HEXAGON SOCKET BUTTON	4					
3	90387–07717	COLLAR	4					
4	BLW–8212B–00	BOX, BATTERY 1	1					
5	90109–06202	BOLT	2					
6	90119–06267	BOLT, WITH WASHER	1					
7	90387–060A7	COLLAR	1					
8	90480–14003	GROMMET	1					
9	90480–01559	GROMMET	2					
10	90464–16061	CLAMP	1					
11	4B4–84334–00	NUT, ADJUSTING	2					
12	90480–09003	GROMMET	2					
13	90338–14008	PLUG	2					
14	BLW–21629–10	GUARD, MUD	1					
15	BLW–2164F–00	STAY 1	1					
16	BLW–2164G–00	STAY 2	1					
17	BAT–21682–00	STAY, PLATE	1					
18	BAT–2161G–00	BRACKET 6	1					
19	1WS–21746–00	DAMPER	1					
20	90387–06372	COLLAR	4					
21	90111–06089	BOLT, HEXAGON SOCKET BUTTON	4					
22	90105–06226	BOLT, FLANGE	4					
23	BLW–2163A–10	COVER, REAR FENDER 1	1					
24	90269–07008	RIVET	2					
25	1RC–2153E–30	EMBLEM, YAMAHA	1					UR FOR DPBMC


FIG. 22 FENDER



BLW1300D0220

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
25	99244–00080	EMBLEM, YAMAHA	1					UR FOR MLNM4
	99247–00080	EMBLEM, YAMAHA	1					UR FOR MDNMD


FIG. 23 SIDE COVER



BLW1300D0230


REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–21711–00–P0	COVER, SIDE 1	1					UR FOR DPBMC
	BLW–21711–00–P1	COVER, SIDE 1	1					UR FOR MLNM4
	BLW–21711–00–P2	COVER, SIDE 1	1					UR FOR MDNMD
2	90109–06259	BOLT	1					
3	90109–05022	BOLT	1					
4	90183–05042	NUT, SPRING	2					
5	90338–06018	PLUG	1					
6	BLW–2171E–00	COVER, SIDE 5	1					
7	90269–06008	RIVET	1					
8	90109–05022	BOLT	1					
9	97702–50016	SCREW,TAPPING	2					
10	90105–08021	BOLT, FLANGE	1					
11	90560–08326	SPACER	1					
12	90464–04005	CLAMP	1					
13	BLW–2171N–00	MOLE, SIDE COVER 3	1					
14	90464–04005	CLAMP	1					
15	BLW–2171L–00	MOLE, SIDE COVER 1	1					
16	90269–06001	RIVET	2					
17	5SL–84753–00	DAMPER	2					
18	BLW–21721–00–P0	COVER, SIDE 2	1					UR FOR DPBMC
	BLW–21721–00–P1	COVER, SIDE 2	1					UR FOR MLNM4
	BLW–21721–00–P2	COVER, SIDE 2	1					UR FOR MDNMD
19	90109–06259	BOLT	1					
20	90109–05022	BOLT	1					
21	90183–05042	NUT, SPRING	2					
22	90338–06018	PLUG	1					
23	BLW–2171X–00	COVER, SIDE 6	1					

FIG. 23 SIDE COVER




REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
24	90269–06008	RIVET	1					
25	90109–05022	BOLT	1					
26	97702–50016	SCREW,TAPPING	2					
27	90105–08021	BOLT, FLANGE	1					
28	90560–08326	SPACER	1					
29	90464–04005	CLAMP	1					
30	BLW–2171R–00	MOLE, SIDE COVER 4	1					
31	90464–04005	CLAMP	1					
32	BLW–2172X–00	COVER, TAILLIGHT	1					
33	97707–50016	SCREW, TRUSS HEAD TAPPING	2					

FIG. 24 REAR ARM



REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–22110–00	REAR ARM COMP.	1					
2	BU2–22358–00	SEAL 1	1					
3	93317–22262	BEARING	3					
4	93106–22019	OIL SEAL (DC 22-28-8)	2					
5	30X–2219X–00	COVER	2					
6	93108–35004	OIL SEAL (35-41-8)	2					
7	90380–16158	BUSH, SOLID	2					
8	BW3–22141–00	SHAFT, PIVOT	1					
9	90201–164H4	WASHER, PLATE	1					
10	90185–16002	NUT, SELF-LOCKING	1					
11	1WS–2217A–00	ARM, RELAY	1					
12	90105–10498	BOLT, FLANGE	2					
13	90387–10132	COLLAR	2					
14	92902–10200	WASHER	1					
15	90185–10011	NUT, SELF-LOCKING	2					
16	93315–31758	BEARING	3					
17	93109–17071	OIL SEAL	6					
18	90387–1012A	COLLAR	3					
19	1WS–22189–00	BOOT, RUBBER	1					
20	1WS–2217F–00	ROD, CONNECTING 1	1					
21	90101–12079	BOLT	1					
22	95602–12200	NUT, SELF-LOCKING	1					
23	93317–31771	BEARING	2					
24	93109–17071	OIL SEAL	2					
25	1WS–22184–00	BUSH	1					
26	BLW–22151–00	SEAL, GUARD	1					
27	90387–06170	COLLAR	1					


FIG. 24 REAR ARM



BLW1300D0240


REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
28	92012–06020	BOLT, BUTTON HEAD	1					
29	90269–07007	RIVET	2					
30	BLW–21650–00	REAR FENDER COMP.	1					
31	90109–06346	BOLT	3					
32	90269–07007	RIVET	2					
33	BLW–2588F–00	HOLDER, BRAKE HOSE 5	1					
34	92017–06010	BOLT, BUTTON HEAD	1					
35	BLW–21668–00	LABEL, TIRE	1					

FIG. 25 REAR SUSPENSION



BLW1300D0250

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–22210–00	SHOCK ABSORBER ASSY, REAR	1					
2	90105–10498	BOLT, FLANGE	1					
3	90185–10011	NUT, SELF-LOCKING	1					
4	90387–1012A	COLLAR	1					
5	90105–10212	BOLT, FLANGE	1					
6	95602–10200	NUT, SELF-LOCKING	1					




BLW1300D0260

FIG. 26 STEERING

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	93399–99931	BEARING	1					
2	1W1–23416–00	COVER, BALL RACE 2	1					
3	90179–25004	NUT	2					
4	90202–26142	WASHER, PLATE	1					
5	26H–23418–01	WASHER, SPECIAL	1					
6	90201–22018	WASHER, PLATE	1					
7	1RC–23393–00	NUT, SPECIAL	1					
8	BLW–23435–01	CROWN, HANDLE	1					
9	91314–08045	BOLT, HEXAGON SOCKET HEAD	2					
10	B34–F3441–10	HOLDER, HANDLE UPPER	2					
11	91314–08030	BOLT, HEXAGON SOCKET HEAD	4					
12	BVA–W000B–00	STEERING BEARING KIT	1					AP


FIG. 27 FRONT FORK



BLW1300D0270

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–23103–00	FRONT FORK ASSY (R.H)	1					
2	BEB–23126–00	.TUBE, OUTER	1					
3	BLW–23120–00	.INNER TUBE COMP.2	1					
4	4EB–23144–00	.SEAL, DUST	1					
5	26H–23156–00	.RING, SNAP	1					
6	4EB–23145–01	.OIL SEAL	1					
7	36Y–23146–10	.WASHER, OIL SEAL	1					
8	1RC–23125–00	.METAL, SLIDE 1	1					
9	4FM–23171–40	.METAL, SLIDE	1					
10	BLW–23170–10	.CYLINDER COMP., FRONT FORK	1					
11	509–23158–L0	.GASKET	1					(KYB)
12	278–23181–50	.BOLT, HEXAGON SOCKET HEAD	1					
13	BLW–23141–00	.SPRING, FRONT FORK	1					
14	1RC–23118–00	.SPACER	1					
15	3LC–23357–00	.NUT	1					
16	BLW–23111–00	.BOLT, CAP	1					
17	39P–23147–00	.O-RING	1					
18	91314–08040	.BOLT, HEXAGON SOCKET HEAD	1					
19	BLW–23102–00	FRONT FORK ASSY (L.H)	1					
20	BEB–23126–00	.TUBE, OUTER	1					
21	BLW–23110–00	.INNER TUBE COMP.1	1					
22	4EB–23144–00	.SEAL, DUST	1					
23	26H–23156–00	.RING, SNAP	1					
24	4EB–23145–01	.OIL SEAL	1					
25	36Y–23146–10	.WASHER, OIL SEAL	1					
26	1RC–23125–00	.METAL, SLIDE 1	1					
27	4FM–23171–40	.METAL, SLIDE	1					

FIG. 27 FRONT FORK



REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
28	BLW–23170–00	.CYLINDER COMP., FRONT FORK	1					
29	509–23158–L0	.GASKET	1					(KYB)
30	278–23181–50	.BOLT, HEXAGON SOCKET HEAD	1					
31	BLW–23141–00	.SPRING, FRONT FORK	1					
32	1RC–23118–00	.SPACER	1					
33	3LC–23357–00	.NUT	1					
34	BLW–23111–00	.BOLT, CAP	1					
35	39P–23147–00	.O-RING	1					
36	BLW–23340–00	UNDER BRACKET COMP.	1					
37	3FV–23462–00	SEAL, STEERING	1					
38	93399–99932	BEARING	1					
39	91314–08030	BOLT, HEXAGON SOCKET HEAD	4					
40	4KM–23123–01	COVER, UNDER 1	1					
41	BBV–W003B–00	FORK SEALS KIT	1					AP





FIG. 28 FUEL TANK


REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–24110–00	FUEL TANK COMP.	1					
2	90480–01558	GROMMET	1					
3	2RP–21719–00	GROMMET	2					
4	BLW–2412Y–00	BRACKET, TANK FITTING	1					
5	BLW–24181–00	DAMPER, LOCATING 1	1					
6	BLW–24183–00	DAMPER, LOCATING 3	1					
7	BLW–24186–00	WASHER, SPECIAL	1					
8	90387–06554	COLLAR	2					
9	95812–06030	BOLT, FLANGE	2					
10	BLW–2413Y–00	BRACKET, TANK FITTING	1					
11	278–27114–00	STOPPER, MAIN STAND	2					
12	90480–16003	GROMMET	2					
13	90387–06287	COLLAR	2					
14	5YU–85886–00	SENSOR, AIR TEMPERATURE	1					
15	98502–05012	SCREW, PAN HEAD	1					
16	90105–06169	BOLT, FLANGE	2					
17	92017–06012	BOLT, BUTTON HEAD	4					
18	BLW–24182–00	DAMPER, LOCATING 2	1					
19	BLW–23429–00	STOPPER	2					
20	BLW–13907–00	FUEL PUMP COMP.	1					
21	BLW–85752–00	.SENDER	1					
22	BLW–24491–00	BRACKET, FUEL PUMP	1					
23	1RC–24486–00	O-RING	1					
24	91312–05010	BOLT, HEXAGON SOCKET HEAD	4					
25	BLW–24602–00	CAP ASSY	1					
26	90110–05112	BOLT, HEXAGON SOCKET HEAD	3					
27	91312–05010	BOLT, HEXAGON SOCKET HEAD	1					

FIG. 28 FUEL TANK



REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
28	BLW–13971–00	PIPE, FUEL 1	1					
29	3TB–24181–00	DAMPER, LOCATING 1	2					
30	BLW–24318–00	PIPE, OVERFLOW	1					
31	90467–090A2	CLIP	1					
32	BLW–24321–00	PIPE 10	1					
33	90467–090A2	CLIP	1					
34	BLW–24312–00	PIPE 2	1					
35	90467–090A2	CLIP	1					
36	BLW–24322–00	PIPE 11	1					
37	BG4–86120–00	SOLENOID VALVE ASSY	1					
38	95707–06500	NUT, FLANGE	1					
39	90387–062M9	COLLAR	1					
40	2RC–24182–00	DAMPER, LOCATING 2	1					
41	BW3–F4170–00	CANISTER ASSY	1					
42	90445–10069	HOSE	1					
43	90467–090A2	CLIP	1					
44	BLW–24135–00	CLAMP 1	1					
45	92017–06010	BOLT, BUTTON HEAD	1					
46	90520–02013	DAMPER, PLATE	2					
47	90520–02826	DAMPER, PLATE	2					
48	3D7–24188–00	MOLD, FUEL TANK	2					


FIG. 29 FUEL TANK 2



BLW1300D0290

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–24129–00–P0	COVER, SIDE 1	1					UR FOR DPBMC
	BLW–24129–00–P1	COVER, SIDE 1	1					UR FOR MLNM4
	BLW–24129–00–P2	COVER, SIDE 1	1					UR FOR MDNMD
2	90160–05014	SCREW, ROUND TAPPING	1					
3	90202–05088	WASHER, PLATE	1					
4	90480–17007	GROMMET	1					
5	90387–10107	COLLAR	1					
6	90110–06087	BOLT, HEXAGON SOCKET HEAD	1					
7	97707–50012	SCREW, TRUSS HEAD TAPPING	2					
8	BLW–24121–00	SEAT, KNEE GRIP 1	1					
9	90269–07923	RIVET	1					
10	90269–06001	RIVET	1					
11	BLW–24139–00–P0	COVER, SIDE 2	1					UR FOR DPBMC
	BLW–24139–00–P1	COVER, SIDE 2	1					UR FOR MLNM4
	BLW–24139–00–P2	COVER, SIDE 2	1					UR FOR MDNMD
12	90160–05014	SCREW, ROUND TAPPING	1					
13	90202–05088	WASHER, PLATE	1					
14	90480–17007	GROMMET	1					
15	90387–10107	COLLAR	1					
16	90110–06087	BOLT, HEXAGON SOCKET HEAD	1					
17	97707–50012	SCREW, TRUSS HEAD TAPPING	2					
18	BLW–24122–00	SEAT, KNEE GRIP 2	1					
19	90269–07923	RIVET	1					
20	90269–06001	RIVET	1					
21	BLW–2137W–00	SCOOP, AIR 1	1					
22	90183–05042	NUT, SPRING	3					
23	90480–01559	GROMMET	1					


FIG. 29 FUEL TANK 2



BLW1300D0290

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
24	BLW–2137X–00	SCOOP, AIR 2	1					
25	90183–05042	NUT, SPRING	3					
26	90480–01559	GROMMET	1					
27	BLW–2836K–00	PANEL, INNER 1	1					
28	97707–50012	SCREW, TRUSS HEAD TAPPING	1					
29	90269–06019	RIVET	1					
30	BLW–2836L–00	PANEL, INNER 2	1					
31	97707–50012	SCREW, TRUSS HEAD TAPPING	1					
32	90269–06019	RIVET	1					
33	BLW–2171A–00	COVER, TOP	1					
34	90183–05042	NUT, SPRING	2					
35	90201–05036	WASHER, PLATE	2					
36	90160–05012	SCREW, ROUND TAPPING	2					
37	1RC–2413B–02	EMBLEM	1					
38	1RC–2413B–02	EMBLEM	1					
39	BLW–82568–00	COVER, MAIN SWITCH	1					
40	8ET–21747–00	DAMPER	1					
41	90159–05065	SCREW, WITH WASHER	2					
42	BLW–24217–00	COVER	1					
43	90269–06008	RIVET	2					
44	BLW–21568–00	LABEL, WARNING	1					
45	BLW–2817K–00	LABEL, FUEL	1					
46	BLW–217F1–00	GRAPHIC, 1	1					UR FOR DPBMC
	BLW–217F1–10	GRAPHIC, 1	1					UR FOR MLNM4
	BLW–217F1–20	GRAPHIC, 1	1					UR FOR MDNMD
47	BLW–217F2–00	GRAPHIC, 2	1					UR FOR DPBMC
	BLW–217F2–10	GRAPHIC, 2	1					UR FOR MLNM4


FIG. 29 FUEL TANK 2



BLW1300D0290

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
47	BLW–217F2–20	GRAPHIC, 2	1					UR FOR MDNMD

FIG. 30 SEAT



REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–24710–00	SINGLE SEAT ASSY	1					
2	BLW–2470F–00	.SEAT COVER COMP.	1					
3	4GL–27114–00	.STOPPER, MAIN STAND	6					
4	90480–14604	.GROMMET	2					
5	90387–07391	.COLLAR	2					
6	BLW–21341–00	BRACKET, SEAT 1	1					
7	90111–06155	BOLT, HEXAGON SOCKET BUTTON	4					
8	90111–06117	BOLT, HEXAGON SOCKET BUTTON	2					
9	BLW–21131–00	BRACKET	1					
10	95D32–06020	BOLT, FLANGE DEEP RECESS	4					
11	BLW–24750–00	TANDEM SEAT ASSY	1					
12	371–27114–00	.STOPPER, MAIN STAND	4					
13	BLW–2471A–00	STAY, SEAT	1					
14	90111–06029	BOLT, HEXAGON SOCKET BUTTON	4					
15	1WD–F4780–00	SEAT LOCK ASSY	1					
16	BLW–2472T–00	COVER, SEAT LOCK	1					
17	95702–06500	NUT, FLANGE	2					
18	BLW–2478E–00	CABLE, SEAT LOCK	1					
19	2TV–W2470–00	ROTOR SET	1					
20	23P–2117K–01	STAY, LOCK	1					
21	90149–06030	SCREW	2					
22	2H7–28151–00	GRIP, DRIVER	1					
23	137–28152–00	DRIVER	1					
24	23P–28164–00	WRENCH, HEXAGON 8	1					
25	BAT–28100–00	TOOL KIT	1					
26	4KG–28186–11	POUCH	1					
27	BLW–28199–E0	MANUAL,OWNER'S	1					UR ENGLISH





FIG. 30 SEAT

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
27	BLW–28199–F0	MANUAL,OWNER'S	1					UR FRENCH
	BLW–28199–G0	MANUAL,OWNER'S	1					UR GERMAN
	BLW–28199–H0	MANUAL,OWNER'S	1					UR ITALIAN
	BLW–28199–S0	MANUAL,OWNER'S	1					UR SPANISH
	BLW–F8199–D0	MANUAL,OWNER'S	1					UR DUTCH
	BLW–F8199–M0	MANUAL,OWNER'S	1					UR SWEDISH
	BLW–F8199–P0	MANUAL,OWNER'S	1					UR PORTUGUESE


FIG. 31 FRONT WHEEL



BLW1300D0310


REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–25168–01–P0	CAST WHEEL, FRONT	1					DPBM15 FOR DPBMC
	BLW–25168–01–P1	CAST WHEEL, FRONT	1					BSC FOR MLNM4
	BLW–25168–01–98	CAST WHEEL, FRONT	1					LGB FOR MDNMD
2	2PP–25117–00	SPACER, BEARING	1					
3	93306–20357	BEARING	2					
4	93102–25017	OIL SEAL	2					
5	94112–17151	TIRE 120/70 ZR17M/C (58W) Q5AF	1					DUNLOP
6	93900–00030	VALVE, RIM (TR412)	1					TAIHEIYO
7	23P–25398–00	BALANCER, WHEEL	1					UN
8	90387–17530	COLLAR	1					
9	90387–17021	COLLAR	1					
10	BLW–25181–00	AXLE, WHEEL	1					
11	BLW–251G3–00	EMBLEM	1					UR FOR DPBMC
	BLW–251G3–10	EMBLEM	1					UR FOR MLNM4
	BLW–251G3–20	EMBLEM	1					UR FOR MDNMD

FIG. 32 FRONT BRAKE CALIPER




REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BAT–2581T–00	DISK BRAKE ASSY	2					
2	90109–064G6	BOLT	10					
3	2DR–2517G–00	ROTOR, SENSOR	1					
4	90149–05029	SCREW	3					
5	1RC–2580T–00	CALIPER ASSY (LEFT)	1					
6	4SV–25802–10	.PISTON ASSY, CALIPER	1					
7	3GM–25803–10	..CALIPER SEAL KIT	1					
8	4SV–25802–00	.PISTON ASSY, CALIPER	1					
9	3MA–25803–10	..CALIPER SEAL KIT	1					
10	5SL–25805–00	.BRAKE PAD KIT	1					
11	13S–25919–00	.SUPPORT, PAD	1					
12	4SV–25924–00	.PIN, PAD	1					
13	3GM–25925–00	.CLIP	2					
14	1J3–25824–00	.SCREW, BLEED	1					
15	306–25825–01	.CAP	1					
16	90105–10440	BOLT, FLANGE	2					
17	1RC–2580U–00	CALIPER ASSY (RIGHT)	1					
18	4SV–25802–10	.PISTON ASSY, CALIPER	1					
19	3GM–25803–10	..CALIPER SEAL KIT	1					
20	4SV–25802–00	.PISTON ASSY, CALIPER	1					
21	3MA–25803–10	..CALIPER SEAL KIT	1					
22	5SL–25805–00	.BRAKE PAD KIT	1					
23	13S–25919–00	.SUPPORT, PAD	1					
24	4SV–25924–00	.PIN, PAD	1					
25	3GM–25925–00	.CLIP	2					
26	1J3–25824–00	.SCREW, BLEED	1					
27	306–25825–01	.CAP	1					

FIG. 32 FRONT BRAKE CALIPER




REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
28	90105–10440	BOLT, FLANGE	2					

FIG. 33 REAR WHEEL




REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–25338–01–P0	CAST WHEEL, REAR	1					DPBM15 FOR DPBMC
	BLW–25338–01–P1	CAST WHEEL, REAR	1					BSC FOR MLNM4
	BLW–25338–01–98	CAST WHEEL, REAR	1					LGB FOR MDNMD
2	93306–20488	BEARING	1					
3	93102–28022	OIL SEAL	1					
4	93306–00449	BEARING	1					
5	2PP–25317–00	SPACER, BEARING	1					
6	94118–17095	TIRE 180/55 ZR17M/C (73W) Q5A	1					DUNLOP
7	93900–00030	VALVE, RIM (TR412)	1					TAIHEIYO
8	23P–25398–00	BALANCER, WHEEL	1					UN
9	20S–25366–00	CLUTCH, HUB	1					
10	93306–20666	BEARING	1					
11	BLW–25383–00	COLLAR, WHEEL	1					
12	93106–40041	OIL SEAL	1					
13	BLW–25443–00	SPROCKET, DRIVEN (43T)	1					
14	90116–10048	BOLT, STUD	6					
15	95602–10200	NUT, SELF-LOCKING	6					
16	BLW–2537W–00	BRACKET 1	1					
17	BLW–25364–00	DAMPER	6					
18	90387–20036	COLLAR	1					
19	90387–20035	COLLAR	1					
20	94A40–24108	SET, CHAIN (DID520VM5 108LE)	1					
21	94682–64021	.JOINT, CHAIN (DID520VM5 ZJ)	1					
22	1WS–25388–00	PULLER, CHAIN 1	2					
23	B34–22174–00	END 1	1					
24	B34–22175–00	END 1	1					
25	95302–08600	NUT, HEXAGON	4					

FIG. 33 REAR WHEEL



REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
26	92902–08600	WASHER, PLATE	2					
27	4FN–22141–00	SHAFT, PIVOT	1					
28	90185–18009	NUT, SELF-LOCKING	1					
29	90201–18021	WASHER, PLATE	1					
30	BLW–2538D–00	COVER, REAR AXLE 1	1					
31	BLW–2538N–00	COVER, REAR AXLE 2	1					
32	BLW–253G1–00	GRAPHIC 1	1					UR FOR DPBMC
	BLW–253G1–10	GRAPHIC 1	1					UR FOR MLNM4
	BLW–253G1–20	GRAPHIC 1	1					UR FOR MDNMD
33	BLW–17460–00	SPROCKET, DRIVE (16T)	1					
34	90208–22002	WASHER, CONICAL SPRING	1					
35	90179–22019	NUT	1					
36	BLW–W001A–00	CHAIN & SPROCKET KIT	1					AP


FIG. 34 REAR BRAKE CALIPER



BLW1300D0340

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	1RC–2582W–00	DISK, REAR BRAKE 2	1					
2	90109–08045	BOLT	5					
3	2DR–2517G–00	ROTOR, SENSOR	1					
4	90149–05029	SCREW	3					
5	2DR–2580W–00	CALIPER ASSY, REAR 2	1					
6	5SL–25802–00	.PISTON ASSY, CALIPER	1					
7	5SL–25803–00	..CALIPER SEAL KIT	1					
8	5SL–25917–00	.BOOT, CALIPER	1					
9	5SL–25838–00	.SLEEVE, CALIPER	1					
10	5SL–25919–00	.SUPPORT, PAD	1					
11	5SL–25914–00	.PIN, SLIDE	1					
12	2DR–25921–50	.BRACKET, SUPPORT	1					
13	3JD–25917–00	.BOOT, CALIPER	1					
14	5VX–25806–00	.BRAKE PAD KIT 2	1					
15	8CR–25924–00	.PIN, PAD	1					
16	5DH–25916–00	.PLUG	1					
17	1RC–25926–00	.BOLT	1					
18	8CR–25824–00	.SCREW, BLEED	1					
19	1UY–25825–51	.CAP	1					
20	5SL–25827–00	.SHIM, CALIPER	1					
21	5SL–25827–10	.SHIM, CALIPER	1					
22	5SL–25828–01	.SHIM, CALIPER	2					


FIG. 35 STEERING HANDLE & CABLE



BLW1300D0350

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–26111–01	HANDLEBAR	1					
2	2C0–26241–00	GRIP	1					
3	BME–26240–00	GRIP ASSY	1					
4	4YR–26246–00	END, GRIP	2					
5	91317–06035	BOLT, HEXAGON SOCKET HEAD	2					
6	BLW–26335–00	WIRE, CLUTCH	1					
7	BLW–2612E–00	BRACKET	1					
8	90111–06101	BOLT, HEXAGON SOCKET BUTTON	1					
9	90464–13073	CLAMP	2					(125.0x7.0)
10	D66–F6280–00	REAR VIEW MIRROR ASSY (LEFT)	1					
11	D66–F6290–00	REAR VIEW MIRROR ASSY (RIGHT)	1					


FIG. 36 FRONT MASTER CYLINDER



BLW1300D0360


REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	1XB–2580A–00	MASTER CYLINDER SUB ASSY 2	1					
2	1WS–25807–00	.CYLINDER KIT, MASTER	1					
3	5VS–25852–00	.CAP, RESERVOIR	1					
4	5VS–25855–00	.BUSH,DIAPHRAGM	1					
5	20S–25854–00	.DIAPHRAGM, RESERVOIR	1					
6	5VS–2589H–00	.SCREW	2					
7	5VS–2589F–00	BOLT, LEVER	1					
8	95617–06100	NUT, SELF-LOCKING	1					
9	5VS–83922–00	LEVER 2	1					
10	5VS–26332–00	BOLT	2					
11	5VS–25867–00	BRACKET, MASTER CYLINDER	1					
12	1HP–83980–03	FRONT STOP SWITCH ASSY	1					
13	98502–04012	SCREW, PAN HEAD	1					
14	92902–04100	WASHER, SPRING	1					
15	92902–04600	WASHER, PLATE	1					
16	BLW–2584C–00	HOSE, BRAKE	1					
17	BLW–25874–00	HOSE, BRAKE 3	1					
18	BLW–2584B–00	HOSE, BRAKE	1					
19	90401–10172	BOLT, UNION	4					
20	90401–10042	BOLT, UNION	1					
21	90430–10005	GASKET	11					
22	BLW–25875–00	HOLDER, BRAKE HOSE 1	1					
23	95027–06025	BOLT, FLANGE	1					
24	BLW–25876–00	HOLDER, BRAKE HOSE 2	1					
25	92017–06012	BOLT, BUTTON HEAD	1					
26	90464–18002	CLAMP	4					

FIG. 37 STAND & FOOTREST




REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–274A3–00	BRACKET, ADAPTER 1	1					
2	90111–10060	BOLT, HEXAGON SOCKET BUTTON	2					
3	BLW–27311–00	STAND, SIDE	1					
4	90101–10034	BOLT	1					
5	90201–101J1	WASHER, PLATE	1					
6	90387–10020	COLLAR	1					
7	90201–10075	WASHER, PLATE	2					
8	90185–10012	NUT, SELF-LOCKING	1					
9	90506–26014	SPRING, TENSION	1					
10	90445–197J2	HOSE (L60)	1					
11	5VX–27315–00	LINK, SIDE STAND	1					
12	1WS–82566–01	SWITCH, SIDE STAND	1					
13	92907–05600	WASHER, PLATE	2					
14	90110–05071	BOLT, HEXAGON SOCKET HEAD	2					
15	95602–05200	NUT, SELF-LOCKING	2					
16	1WS–27321–00	BRACKET, SIDE STAND	1					
17	90111–10058	BOLT, HEXAGON SOCKET BUTTON	2					
18	BMG–27451–00	FOOTREST 3	1					
19	91701–08040	PIN	1					
20	91402–25015	PIN, COTTER	1					
21	90508–18135	SPRING, TORSION	1					
22	BLW–27413–00	COVER, FOOTREST	1					
23	90109–08233	BOLT	1					
24	BLW–27442–00	BRACKET 2	1					
25	BLW–27498–00	SEAT 1	1					
26	BLW–27445–00	PLATE 1	1					
27	92017–08016	BOLT, BUTTON HEAD	2					

FIG. 37 STAND & FOOTREST



BLW1300D0370

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
28	BLW–18110–00	SHIFT PEDAL ASSY	1					
29	1WS–18113–00	.COVER, SHIFT PEDAL	1					
30	90201–12051	WASHER, PLATE	1					
31	90206–12074	WASHER, WAVE	1					
32	4BP–27434–01	BOLT	1					
33	90201–08053	WASHER, PLATE	1					
34	5A8–18115–00	ROD, SHIFT	1					
35	90170–06026	NUT	1					
36	95314–06700	NUT	1					
37	90110–08220	BOLT, HEXAGON SOCKET HEAD	2					
38	BLW–27453–00	COVER 1	1					
39	90109–06346	BOLT	2					
40	90269–08008	RIVET	1					
41	B7N–27431–00	FOOTREST, REAR 1	1					
42	BLW–2741L–00	BRACKET 4	1					
43	90501–12743	SPRING, COMPRESSION	1					
44	93501–04011	BALL	1					
45	5VX–27437–00	WASHER, SPECIAL	1					
46	90240–08063	PIN, CLEVIS	1					
47	91402–25015	PIN, COTTER	1					
48	90110–08111	BOLT, HEXAGON SOCKET HEAD	2					




BLW1300D0380

FIG. 38 STAND & FOOTREST 2

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	B34–274A4–00	BRACKET,ADAPTER 2	1					
2	90111–10060	BOLT, HEXAGON SOCKET BUTTON	2					
3	BLW–15484–00	CLAMP 2	1					
4	95022–06010	BOLT, FLANGE	1					
5	BMG–27461–00	FOOTREST 4	1					
6	91701–08040	PIN	1					
7	91402–25015	PIN, COTTER	1					
8	90508–18135	SPRING, TORSION	1					
9	BLW–27413–00	COVER, FOOTREST	1					
10	90109–08233	BOLT	1					
11	BLW–27443–00	BRACKET 3	1					
12	BLW–27499–00	SEAT 2	1					
13	BLW–27446–00	PLATE 2	1					
14	92017–08030	BOLT, BUTTON HEAD	2					
15	BLW–27211–00	PEDAL, BRAKE	1					
16	90206–12074	WASHER, WAVE	1					
17	4BP–27434–01	BOLT	1					
18	90201–12051	WASHER, PLATE	1					
19	90201–08053	WASHER, PLATE	1					
20	90506–23008	SPRING, TENSION	1					
21	90110–08220	BOLT, HEXAGON SOCKET HEAD	2					
22	BLW–27463–00	COVER 2	1					
23	90109–06346	BOLT	2					
24	90269–08008	RIVET	1					
25	B7N–27441–00	FOOTREST, REAR 2	1					
26	BLW–2742L–00	BRACKET 5	1					
27	90501–12743	SPRING, COMPRESSION	1					


FIG. 38 STAND & FOOTREST 2




BLW1300D0380

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
28	93501–04011	BALL	1					
29	5VX–27437–00	WASHER, SPECIAL	1					
30	90240–08063	PIN, CLEVIS	1					
31	91402–25015	PIN, COTTER	1					
32	90110–08111	BOLT, HEXAGON SOCKET HEAD	2					

FIG. 39 REAR MASTER CYLINDER




REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–2583V–00	RR. MASTER CYLINDER ASSY.	1					
2	5VX–25808–00	.CYLINDER KIT, MASTER	1					
3	3LN–25868–01	.BOOT, MASTER CYLINDER	1					
4	2D1–2582A–01	.JOINT	1					
5	4BP–2585F–01	.O-RING	1					
6	4BP–27222–02	.JOINT	1					
7	90170–08010	.NUT	2					
8	90240–08005	PIN, CLEVIS	1					
9	90201–08070	WASHER, PLATE	1					
10	91401–20012	PIN, COTTER	1					
11	14B–25894–00	TANK, RESERVOIR	1					
12	2C0–25852–00	CAP, RESERVOIR	1					
13	2VN–25854–00	DIAPHRAGM, RESERVOIR	1					
14	2VN–25855–00	BUSH,DIAPHRAGM	1					
15	90387–05028	COLLAR	1					
16	2C0–26326–00	GROMMET	1					
17	90467–11044	CLIP	2					
18	BLW–25895–00	HOSE, RESERVOIR	1					
19	BLW–82530–00	STOP SWITCH ASSY	1					
20	BLW–2144G–00	STAY, STOP SWITCH	1					
21	95027–06012	BOLT, FLANGE	1					
22	1WS–2582E–00	HOLDER, RESERVE TANK	1					
23	95707–05500	NUT, FLANGE	1					
24	90464–17008	CLAMP	1					
25	BLW–2584D–00	HOSE, BRAKE	1					
26	BLW–2584E–00	BRAKE HOSE ASSY 5	1					
27	90464–07014	CLAMP	1					



BLW1300D0390

FIG. 39 REAR MASTER CYLINDER

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
28	90105–06148	BOLT, FLANGE	1					
29	90464–07009	CLAMP	1					
30	90401–10020	BOLT, UNION	2					
31	90430–10005	GASKET	4					
32	90401–10172	BOLT, UNION	2					
33	90430–10005	GASKET	4					
34	92012–06010	BOLT, BUTTON HEAD	1					
35	90464–16001	CLAMP	1					




BLW1300D0400

FIG. 40 GENERATOR


REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–81410–00	STATOR ASSY	1					
2	BLW–81450–00	ROTOR ASSY	1					
3	90110–06223	BOLT, HEXAGON SOCKET HEAD	3					
4	90149–06109	SCREW	2					
5	1WS–15484–00	CLAMP 2	1					

FIG. 41 STARTING MOTOR



BLW1300D0410

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	1WS–81890–00	MOTOR ASSY	1					
2	4B5–81844–00	.GASKET	2					
3	1FK–81847–00	.O-RING	1					
4	4XV–8182A–00	.NUT	1					
5	18P–81826–00	.BOLT	2					
6	18P–81801–00	.BRUSH SET	1					
7	1WS–81815–00	CORD, STARTER MOTOR	1					
8	4B5–81871–00	.CAP	1					
9	4XV–8182A–00	NUT	1					
10	91312–06025	BOLT, HEXAGON SOCKET HEAD	2					




BLW1300D0420

FIG. 42 FLASHER LIGHT

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	B5Y–H330B–00	FLASHER LIGHT ASSY B	1					
2	B5Y–H330A–00	FLASHER LIGHT ASSY A	1					
3	B1X–H330B–00	FLASHER LIGHT ASSY B	1					
4	BEA–H330A–00	FLASHER LIGHT ASSY A	1					


FIG. 43 METER



BLW1300D0430

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–83220–01	CONNECTED METER ASSY. (KM/H)	1					UR EXCEPT FOR GBR
	BLW–83220–10	CONNECTED METER ASSY. (MPH)	1					UR FOR GBR
2	90160–05017	SCREW, ROUND TAPPING	3					
3	90201–05036	WASHER, PLATE	3					
4	4XV–83513–00	DAMPER	3					
5	BLW–83519–00	BRACKET, METER	1					
6	90183–05076	NUT, SPRING	2					
7	90111–06156	BOLT, HEXAGON SOCKET BUTTON	2					
8	90201–06029	WASHER, PLATE	2					
9	90480–12314	GROMMET	2					
10	90387–06159	COLLAR	2					
11	90183–05076	NUT, SPRING	4					
12	95D37–06025	BOLT, FLANGE DEEP RECESS	2					
13	90480–12314	GROMMET	2					
14	90387–06159	COLLAR	2					


FIG. 44 HEADLIGHT



BLW1300D0440


REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BME–84300–00	HEADLIGHT ASSY	1					
2	BME–85490–00	.LIGHT CONTROL UNIT	1					
3	2PW–84192–00	.SCREW, SPECIAL	2					
4	90387–06161	COLLAR	3					
5	95822–06020	BOLT, FLANGE	3					
6	4XV–83513–00	DAMPER	3					
7	90480–10003	GROMMET	1					
8	BLW–84301–00	PILOT LIGHT ASSY 1	1					
9	90183–05042	NUT, SPRING	1					
10	97707–50012	SCREW, TRUSS HEAD TAPPING	1					
11	90111–05002	BOLT, HEXAGON SOCKET BUTTON	4					
12	90111–05034	BOLT, HEXAGON SOCKET BUTTON	1					
13	BLW–84302–00	PILOT LIGHT ASSY 2	1					
14	90183–05042	NUT, SPRING	1					
15	97707–50012	SCREW, TRUSS HEAD TAPPING	1					
16	90111–05002	BOLT, HEXAGON SOCKET BUTTON	2					
17	BLW–2838E–00–P0	COVER, HEADLIGHT	1					MBM3 FOR DPBMC
	BLW–2838E–00–P1	COVER, HEADLIGHT	1					FOR MLNM4
	BLW–2838E–00–P2	COVER, HEADLIGHT	1					FOR MDNMD
18	90111–05021	BOLT, HEXAGON SOCKET BUTTON	1					
19	90520–10023	DAMPER, PLATE	2					
20	BLW–23122–00	COVER, OUTER 1	1					
21	90183–05076	NUT, SPRING	4					
22	90183–05042	NUT, SPRING	2					
23	97707–50012	SCREW, TRUSS HEAD TAPPING	2					
24	90520–10023	DAMPER, PLATE	2					
25	BLW–84369–00	COVER 1	1					

FIG. 44 HEADLIGHT



BLW1300D0440

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
26	90111–05021	BOLT, HEXAGON SOCKET BUTTON	2					




BLW1300D0450

FIG. 45 TAILLIGHT

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–84700–00	TAILLIGHT ASSY	1					
2	90111–06137	BOLT, HEXAGON SOCKET BUTTON	2					
3	90387–067V1	COLLAR	2					
4	90480–13001	GROMMET	2					
5	90183–05042	NUT, SPRING	2					
6	90480–10016	GROMMET	2					
7	2PN–84745–02	LICENCE LIGHT UNIT ASSY	1					
8	2DP–H4347–00	.BULB (12V-5W)	1					
9	90119–05020	BOLT, WITH WASHER	2					
10	90387–05042	COLLAR	2					
11	90480–11009	GROMMET	2					
12	90183–05076	NUT, SPRING	2					


FIG. 46 HANDLE SWITCH & LEVER



BLW1300D0460

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	1B3–82911–00	HOLDER, LEVER 1	1					
2	5EB–83912–03	LEVER 1	1					
3	2C0–83945–00	BOLT, LEVER	1					
4	95607–06200	NUT, SELF U-FLANGE	1					
5	95027–06020	BOLT, FLANGE	1					
6	5LV–83951–00	BOLT, CABLE ADJUSTING	1					
7	4XV–83929–00	PLATE, SPRING	1					
8	3YX–82917–01	SWITCH	1					
9	98704–03020	SCREW, FLAT HEAD	1					
10	98507–04010	SCREW, PAN HEAD	1					
11	5JJ–83913–00	COLLAR, LEVER 1	1					
12	90465–10098	CLAMP	3					
13	BLW–8291L–00	SW., HANDLE LH	1					
14	BME–83525–00	CLIP	1					
15	98507–04016	SCREW, PAN HEAD	1					
16	BME–8246B–00	COVER 1	1					
17	98507–04018	SCREW, PAN HEAD	1					
18	BME–8291R–00	SW., HANDLE RH	1					
19	BME–8249A–00	COVER 2	1					
20	98507–04018	SCREW, PAN HEAD	1					

FIG. 47 ELECTRICAL 1



REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	5TJ–82100–02	BATTERY ASSY (YTZ7S(F))	1					
2	3L8–82131–01	BAND, BATTERY	1					
3	B7N–81940–00	STARTER RELAY ASSY (RC19-107A)	1					
4	5SL–82119–10	COVER, LEAD WIRE	1					
5	95022–06008	BOLT, FLANGE	2					
6	BLW–82590–00	WIRE HARNESS ASSY	1					
7	1CB–82151–10	.FUSE (7.5A-LP BL)	7					
8	BMG–82151–30	.FUSE (10A)	3					
9	BMG–82151–90	.FUSE (15A)	4					
10	BMG–82151–60	.FUSE (30A)	2					
11	BMG–82151–B0	.FUSE (50A)	1					
12	1CB–82151–00	.FUSE (5A-LP BL)	2					
13	91380–06016	BOLT	1					
14	90464–20191	CLAMP	1					
15	90464–14010	CLAMP	1					
16	90464–80002	CLAMP	1					
17	1UA–82591–00	BAND	8					
18	90464–65001	CLAMP	1					
19	1WS–81916–00	COVER, TERMINAL	1					
20	90464–14010	CLAMP	1					
21	BME–81963–01	GENERATOR CONTROL UNIT	1					
22	5VK–81950–53	RELAY ASSY (G8R-30Y-W5)	1					
23	1WS–8246B–00	COVER 1	1					
24	1TP–81950–00	RELAY ASSY (1TP-00)	4					
25	5EA–81952–00	.HOLDER, RELAY	1					
26	5PS–82576–02	SENSOR, LEAN ANGLE	1					
27	97702–40025	SCREW, TAPPING	2					





FIG. 47 ELECTRICAL 1


REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
28	90201–04030	WASHER, PLATE	2					
29	90464–17003	CLAMP	1					
30	90464–16001	CLAMP	1					
31	90464–18004	CLAMP	1					

FIG. 48 ELECTRICAL 2




REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–W8250–01	MAIN SW. IMMOBILIZER KIT	1					
2	BLW–8591A–00	.ENGINE CONTROL UNIT ASSY	1					
3	BME–8255P–01	.IMMOBILIZER. UNIT COMP.	1					
4	5SL–82113–01	.SCREW	2					
5	5SL–82511–08	BLANK KEY	1					AP
6	1WS–82380–00	SENSOR, PRESSURE	1					
7	91312–05020	BOLT, HEXAGON SOCKET HEAD	1					
8	BME–82310–00	IGNITION COIL ASSY	2					
9	2HC–85899–10	SENSOR, GEAR POSITION	1					
10	93210–17008	O-RING	1					
11	BLW–15191–00	PLATE	1					
12	90110–05011	BOLT, HEXAGON SOCKET HEAD	2					
13	4P9–83591–00	THERMO UNIT	1					
14	90430–10004	GASKET	1					
15	1WS–82504–01	OIL PRESSURE SWITCH ASSY	1					
16	1WS–81315–00	LEAD WIRE ASSY	1					
17	BLW–82309–00	WIRE, SUB LEAD	1					
18	5ES–82540–00	NEUTRAL SWITCH ASSY	1					
19	BFD–82509–00	WIRE, SUB LEAD	1					
20	90201–12790	WASHER, PLATE	1					
21	90111–08094	BOLT, HEXAGON SOCKET BUTTON	2					
22	BLW–82915–00	HOLDER, LEVER UNDER	1					
23	133–82131–00	BAND, BATTERY	1					
24	90109–063F1	BOLT	1					
25	90109–06183	BOLT	2					
26	BLW–81952–00	HOLDER, RELAY	1					
27	90109–06172	BOLT	1					

FIG. 48 ELECTRICAL 2



REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
28	90109–06183	BOLT	1					
29	BLW–82514–00	STAY, MAIN SWITCH	1					
30	BMG–85903–20	BODY CONT,MODULE ASSY	1					
31	97702–60520	SCREW, TAPPING	2					
32	90480–01558	GROMMET	2					
33	90179–05523	NUT	2					
34	90464–36005	CLAMP	1					
35	BEA–83371–00	HORN	1					
36	90105–06048	BOLT, FLANGE	1					
37	3Y6–85130–02	REAR REFLECTOR ASSY	1					
38	95602–05200	NUT, SELF-LOCKING	1					
39	59C–85131–00	REFLECTOR, REAR 1	2					
40	BLW–85112–00	BRACKET, REFLECTOR 1	1					
41	BLW–85122–00	BRACKET, REFLECTOR 2	1					
42	95702–05500	NUT, FLANGE	2					

FIG. 49 ELECTRICAL 3



BLW1300D0490

REF. NO.	PART NO.	DESCRIPTION	BLW1					REMARKS
1	BLW–85930–07	HYDRAULIC UNIT ASSY	1					
2	90480–14229	GROMMET	3					
3	90387–06289	COLLAR	3					
4	95817–06020	BOLT, FLANGE	3					
5	BLW–85970–01	WHEEL SENSOR ASSY, FRONT	1					
6	92017–06016	BOLT, BUTTON HEAD	1					
7	90464–14010	CLAMP	2					
8	90464–12013	CLAMP	2					
9	BLW–85980–00	WHEEL SENSOR ASSY, REAR	1					
10	92014–06014	BOLT, BUTTON HEAD	1					
11	90464–10233	CLAMP	2					
12	90464–30009	CLAMP	1					
13	BLW–2175T–00	BRACKET 1	1					
14	92012–06045	BOLT, BUTTON HEAD	1					
15	92012–06016	BOLT, BUTTON HEAD	1					

PART NO.	REF. NO.
BAT–11101–09	3 – 1
5VY–1111G–00	3 – 11
	3 – 22
4D9–11133–10	3 – 2
1WS–11165–01	3 – 17
BLW–11166–00	11 – 25
1WS–11169–00	3 – 18
BLW–11181–00	3 – 14
1WS–11190–10	3 – 16
1WS–11193–01	3 – 20
214–11198–01	10 – 7
BLW–11400–00	4 – 1
2S3–11413–00	4 – 22
2S3–11413–10	4 – 22
2S3–11413–20	4 – 22
2S3–11413–30	4 – 22
2S3–11413–40	4 – 22
BLW–11416–00	4 – 5
BLW–11416–10	4 – 5
BLW–11416–20	4 – 5
BLW–11416–A0	4 – 5
BLW–11416–B0	4 – 5
1WS–11454–00	4 – 14
1WS–11496–00	4 – 15
BLW–11500–00	4 – 13
1WS–11531–00	4 – 16
1WS–11533–00	4 – 19
BLW–11603–00	4 – 7
1WS–11631–00	4 – 6
1WS–11633–00	4 – 8
BLW–11650–00	4 – 2
1RC–11654–00	4 – 3
BME–11656–00	4 – 4
BME–11656–10	4 – 4
BME–11656–20	4 – 4
BME–11656–30	4 – 4
BLW–12111–00	5 – 1
1WS–12113–01	5 – 3
1WS–12114–00	5 – 4
1WS–12116–00	5 – 8
1WS–12117–00	5 – 5
1WG–12118–00	5 – 6
4TE–12119–00	5 – 7
1WS–12121–01	5 – 2
B4T–12153–00	5 – 9
4C8–12153–09	5 – 9
1HX–12168–F0	5 – 10
1HX–12168–H1	5 – 10
1HX–12168–K1	5 – 10
1HX–12168–M1	5 – 10
1HX–12168–R1	5 – 10
1HX–12168–U1	5 – 10
1HX–12168–W1	5 – 10
1HX–12168–Y1	5 – 10
1HX–12169–11	5 – 10
1HX–12169–31	5 – 10
1HX–12169–50	5 – 10
1HX–12169–70	5 – 10
1HX–12169–90	5 – 10
1HX–12169–E0	5 – 10
1HX–12169–G0	5 – 10
1HX–12169–J0	5 – 10
1HX–12169–L0	5 – 10
1HX–12169–N0	5 – 10
1HX–12169–T0	5 – 10
BLW–12170–00	6 – 1
BAT–12176–00	6 – 2
1WS–12180–10	6 – 4
1WS–12210–02	6 – 12
1WS–12213–00	6 – 15
5SL–12214–00	6 – 14
5EL–12228–00	6 – 13
1WS–12247–00	6 – 8
1WS–12251–00	6 – 17
1WS–12252–00	6 – 18
1WS–12257–00	6 – 9
1WS–12280–00	6 – 6
1PD–12288–00	6 – 10
BEB–12405–00	8 – 2
1WS–12410–01	7 – 17
BLW–12413–00	7 – 18
BLW–12420–00	7 – 24
1WS–12422–10	7 – 30
5VK–12438–00	7 – 27
1WS–12439–00	7 – 31
1WS–12450–00	7 – 25
BLW–12461–00	8 – 1
5SL–12462–01	8 – 9
1WS–12469–00	7 – 14
1WS–12481–01	7 – 1
1WS–12482–01	7 – 3
1WS–12576–00	7 – 9
	7 – 10
1WS–12578–00	8 – 10
1WS–12588–01	7 – 20
1WS–12589–01	7 – 22
1WS–12671–00	8 – 3
	8 – 5
2S3–12675–00	8 – 4
BBW–12858–00	10 – 3
5VY–13117–10	9 – 9
BLW–13300–00	9 – 1
2CR–13338–00	7 – 28
1WS–13410–00	9 – 6
BLW–13414–00	10 – 8
BLW–13417–00	10 – 5
5GH–13440–90	1 – 2
	10 – 4
1WS–13470–00	10 – 1
1XD–13475–00	10 – 2
BLW–13542–00	11 – 4
8FP–13556–00	12 – 2
14B–13573–00	12 – 7
1WS–13635–00	11 – 1
BLW–13750–00	12 – 1
1WS–13761–00	12 – 3
BLW–13907–00	28 – 20
BLW–13971–00	28 – 28
2C0–14105–00	12 – 15
8A7–14139–00	12 – 14
5PS–14147–00	12 – 4
895–14169–00	12 – 13
363–14198–00	12 – 8
8CC–14216–10	12 – 5
BLW–14401–00	11 – 5
BLW–14417–00	11 – 6
BLW–14418–00	11 – 8
BLW–14437–00	11 – 15
1WS–1443E–00	11 – 18
1WS–14450–00	1 – 3
	11 – 10
1WS–14452–00	11 – 11
1WS–14465–00	12 – 12
14B–14466–00	12 – 9
BLW–14469–00	11 – 12
BLW–1446C–00	11 – 13
4XY–14568–00	8 – 18
3YF–14613–01	13 – 6
B4T–14628–10	13 – 11
BLW–14703–00	13 – 1
BLW–14708–00	13 – 2
BLW–15100–09	14 – 1
BLW–15128–00	14 – 21
5EB–15155–00	14 – 2
1WS–15156–00	14 – 11
BME–15189–00	14 – 5
36Y–15189–01	14 – 8
BLW–15191–00	48 – 11
2H7–15361–00	14 – 7
BAT–15362–00	15 – 19
BLW–15377–00	15 – 12
BLW–15411–00	15 – 1
1WS–15416–10	14 – 18
BLW–15418–00	15 – 11
BLW–15421–00	7 – 34
BLW–15441–00	15 – 17
BLW–15451–00	15 – 7
BLW–15456–00	14 – 19
BLW–15461–00	2 – 2
	17 – 27
1WS–15484–00	40 – 5
BLW–15484–00	15 – 16
	38 – 3
B5Y–1548B–00	15 – 21
1WS–15512–00	16 – 5
BLW–15515–00	16 – 1
BLW–15517–00	16 – 6
23P–15521–00	16 – 4
1WS–15590–00	16 – 2
1WS–16150–00	17 – 1
363–16154–00	17 – 2
	17 – 18
BEB–16173–00	2 – 7
	17 – 9
1WS–16181–00	17 – 16
B7N–16321–00	2 – 3
	2 – 11
	17 – 4
1TD–16324–00	2 – 6
	17 – 7
BR9–16324–10	2 – 8
	2 – 9
	17 – 14
	17 – 15
4B1–16325–00	2 – 8
	2 – 9
	17 – 14
	17 – 15
5VY–16325–10	2 – 5
	2 – 8
	2 – 9
	17 – 6
5VY–16325–10	17 – 14
	17 – 15
B90–16331–00	2 – 4
	2 – 12
	17 – 5
2CR–16337–00	17 – 11
1WS–16340–01	17 – 23
132–16346–00	20 – 2
BEB–16350–00	17 – 8
B90–16352–00	17 – 10
1WS–16356–00	17 – 22
BEB–16371–00	17 – 3
2D1–16382–00	7 – 35
1TD–16383–01	17 – 12
1TD–16384–00	17 – 13
1WS–17121–00	18 – 13
1WS–17131–00	18 – 6
BLW–17151–00	18 – 2
BLW–17161–00	18 – 9
BLW–17211–00	18 – 38
BLW–17221–00	18 – 22
BLW–17231–00	18 – 33
1WS–17241–00	18 – 29
BLW–17251–00	18 – 37
BLW–17261–00	18 – 26
BLW–17401–00	18 – 1
1WS–17421–00	18 – 17
1WS–17446–00	18 – 15
BLW–17460–00	2 – 27
	33 – 33
1WS–18101–00	20 – 4
BLW–18110–00	37 – 28
BLW–18112–00	20 – 14
1WS–18113–00	37 – 29
5A8–18115–00	37 – 34
1D7–18127–00	20 – 3
1WS–18140–00	20 – 7
2C0–18175–00	20 – 6
1WS–18511–00	19 – 2
1WS–18512–00	19 – 3
1WS–18513–00	19 – 4
20S–18535–00	19 – 5
1WS–18536–00	19 – 6
BLW–18540–00	19 – 1
BLW–21110–10	21 – 1
1RC–2111D–00	11 – 7
	11 – 9
BLW–21131–00	30 – 9
BLW–2115L–00	21 – 26
23P–2117K–01	30 – 20
BLW–21288–00	21 – 28
BLW–21315–00	21 – 9
BLW–21316–00	21 – 10
BLW–21341–00	30 – 6
BLW–2137W–00	29 – 21
BLW–2137X–00	29 – 24
BLW–2141G–00	21 – 30
20S–21445–01	13 – 8
BLW–2144G–00	39 – 20
BLW–21511–00–P0	22 – 1
BLW–21511–00–P1	22 – 1
BLW–21511–00–P2	22 – 1
1RC–2153E–30	22 – 25
BLW–21568–00	29 – 44
BLW–21596–00	21 – 15
BAT–2161G–00	22 – 18
1WS–2161J–00	21 – 22
BLW–21629–10	22 – 14
BLW–2163A–10	22 – 23
BLW–2164F–00	22 – 15
BLW–2164G–00	22 – 16
BLW–21650–00	24 – 30
BLW–21668–00	24 – 35
BAT–21682–00	22 – 17
BLW–21711–00–P0	23 – 1
BLW–21711–00–P1	23 – 1
BLW–21711–00–P2	23 – 1
2RP–21719–00	28 – 3
BLW–2171A–00	29 – 33
BLW–2171E–00	23 – 6
BLW–2171L–00	23 – 15
BLW–2171N–00	23 – 13
BLW–2171R–00	23 – 30
BLW–2171X–00	23 – 23
BLW–21721–00–P0	23 – 18
BLW–21721–00–P1	23 – 18
BLW–21721–00–P2	23 – 18
BLW–2172A–00	8 – 31
BLW–2172W–00	8 – 19
BLW–2172X–00	23 – 32
BLW–21731–00	8 – 25
BLW–21741–00	8 – 28
1WS–21746–00	22 – 19
8ET–21747–00	29 – 40
BLW–2175T–00	49 – 13
BLW–2175U–00	21 – 24

PART NO.	REF. NO.
BLW–217F1–00	29 – 46
BLW–217F1–10	29 – 46
BLW–217F1–20	29 – 46
BLW–217F2–00	29 – 47
BLW–217F2–10	29 – 47
BLW–217F2–20	29 – 47
BEB–21816–00	8 – 17
BEB–21817–00	8 – 15
26H–21828–00	8 – 14
BLW–21871–00	8 – 13
3P6–21875–00	8 – 16
1WS–2191B–00	21 – 2
BLW–22110–00	24 – 1
4FN–22141–00	33 – 27
BW3–22141–00	24 – 8
BLW–22151–00	24 – 26
B34–22174–00	33 – 23
B34–22175–00	33 – 24
1WS–2217A–00	24 – 11
1WS–2217F–00	24 – 20
1WS–22184–00	24 – 25
1WS–22189–00	24 – 19
30X–2219X–00	24 – 5
BLW–22210–00	25 – 1
BU2–22358–00	24 – 2
BLW–23102–00	27 – 19
BLW–23103–00	27 – 1
BLW–23110–00	27 – 21
BLW–23111–00	27 – 16
	27 – 34
1RC–23118–00	27 – 14
	27 – 32
BLW–23120–00	27 – 3
BLW–23122–00	44 – 20
4KM–23123–01	27 – 40
1RC–23125–00	2 – 17
	27 – 8
	27 – 26
BEB–23126–00	27 – 2
	27 – 20
BLW–23141–00	27 – 13
	27 – 31
4EB–23144–00	2 – 14
	27 – 4
	27 – 22
4EB–23145–01	2 – 16
	27 – 6
	27 – 24
36Y–23146–10	27 – 7
	27 – 25
39P–23147–00	2 – 20
	27 – 17
	27 – 35
26H–23156–00	2 – 15
	27 – 5
	27 – 23
509–23158–L0	2 – 19
	27 – 11
	27 – 29
BLW–23170–00	27 – 28
BLW–23170–10	27 – 10
4FM–23171–40	2 – 18
	27 – 9
	27 – 27
278–23181–50	27 – 12
	27 – 30
BLW–23340–00	27 – 36
3LC–23357–00	27 – 15
	27 – 33
1RC–23393–00	26 – 7
1W1–23416–00	2 – 25
	26 – 2
26H–23418–01	26 – 5
BLW–23429–00	28 – 19
BLW–23435–01	26 – 8
3FV–23462–00	2 – 23
	27 – 37
BLW–24110–00	28 – 1
BLW–24121–00	29 – 8
BLW–24122–00	29 – 18
BLW–24129–00–P0	29 – 1
BLW–24129–00–P1	29 – 1
BLW–24129–00–P2	29 – 1
BLW–2412Y–00	28 – 4
BLW–24135–00	28 – 44
BLW–24139–00–P0	29 – 11
BLW–24139–00–P1	29 – 11
BLW–24139–00–P2	29 – 11
1RC–2413B–02	29 – 37
	29 – 38
BLW–2413Y–00	28 – 10
3HA–24141–00	21 – 32
3TB–24181–00	28 – 29
BLW–24181–00	28 – 5
2RC–24182–00	28 – 40
BLW–24182–00	28 – 18
BLW–24183–00	28 – 6
BLW–24186–00	28 – 7
3D7–24188–00	28 – 48
BLW–24217–00	29 – 42
BLW–24312–00	28 – 34
BLW–24318–00	28 – 30
BLW–24321–00	28 – 32
BLW–24322–00	28 – 36
1RC–24486–00	28 – 23
BLW–24491–00	28 – 22
BLW–24602–00	28 – 25
BLW–2470F–00	30 – 2
BLW–24710–00	30 – 1
BLW–2471A–00	30 – 13
BLW–2472T–00	30 – 16
BLW–24750–00	30 – 11
BLW–2478E–00	30 – 18
2PP–25117–00	31 – 2
BLW–25168–01–98	31 – 1
BLW–25168–01–P0	31 – 1
BLW–25168–01–P1	31 – 1
2DR–2517G–00	32 – 3
	34 – 3
BLW–25181–00	31 – 10
BLW–251G3–00	31 – 11
BLW–251G3–10	31 – 11
BLW–251G3–20	31 – 11
2PP–25317–00	33 – 5
BLW–25338–01–98	33 – 1
BLW–25338–01–P0	33 – 1
BLW–25338–01–P1	33 – 1
BLW–25364–00	33 – 17
20S–25366–00	33 – 9
BLW–2537W–00	33 – 16
BLW–25383–00	33 – 11
1WS–25388–00	33 – 22
BLW–2538D–00	33 – 30
BLW–2538N–00	33 – 31
23P–25398–00	31 – 7
	33 – 8
BLW–253G1–00	33 – 32
BLW–253G1–10	33 – 32
BLW–253G1–20	33 – 32
BLW–25443–00	2 – 30
	33 – 13
4SV–25802–00	32 – 8
	32 – 20
5SL–25802–00	34 – 6
4SV–25802–10	32 – 6
	32 – 18
5SL–25803–00	34 – 7
3GM–25803–10	32 – 7
	32 – 19
3MA–25803–10	32 – 9
	32 – 21
5SL–25805–00	1 – 4
	32 – 10
	32 – 22
5VX–25806–00	1 – 5
	34 – 14
1WS–25807–00	36 – 2
5VX–25808–00	39 – 2
1XB–2580A–00	36 – 1
1RC–2580T–00	32 – 5
1RC–2580U–00	32 – 17
2DR–2580W–00	34 – 5
BAT–2581T–00	32 – 1
1J3–25824–00	32 – 14
	32 – 26
8CR–25824–00	34 – 18
306–25825–01	32 – 15
	32 – 27
1UY–25825–51	34 – 19
5SL–25827–00	34 – 20
5SL–25827–10	34 – 21
5SL–25828–01	34 – 22
2D1–2582A–01	39 – 4
1WS–2582E–00	39 – 22
1RC–2582W–00	34 – 1
5SL–25838–00	34 – 9
BLW–2583V–00	39 – 1
BLW–2584B–00	36 – 18
BLW–2584C–00	36 – 16
BLW–2584D–00	39 – 25
BLW–2584E–00	39 – 26
2C0–25852–00	39 – 12
5VS–25852–00	36 – 3
20S–25854–00	36 – 5
2VN–25854–00	39 – 13
2VN–25855–00	39 – 14
5VS–25855–00	36 – 4
4BP–2585F–01	39 – 5
5VS–25867–00	36 – 11
3LN–25868–01	39 – 3
BLW–25874–00	36 – 17
BLW–25875–00	36 – 22
BLW–25876–00	36 – 24
BLW–2588F–00	24 – 33
14B–25894–00	39 – 11
BLW–25895–00	39 – 18
5VS–2589F–00	36 – 7
5VS–2589H–00	36 – 6
5SL–25914–00	34 – 11
5DH–25916–00	34 – 16
3JD–25917–00	34 – 13
5SL–25917–00	34 – 8
13S–25919–00	32 – 11
	32 – 23
5SL–25919–00	34 – 10
2DR–25921–50	34 – 12
4SV–25924–00	32 – 12
	32 – 24
8CR–25924–00	34 – 15
3GM–25925–00	32 – 13
	32 – 25
1RC–25926–00	34 – 17
BLW–26111–01	35 – 1
BLW–2612E–00	35 – 7
BME–26240–00	35 – 3
2C0–26241–00	35 – 2
4YR–26246–00	35 – 4
2C0–26326–00	39 – 16
5VS–26332–00	36 – 10
BLW–26335–00	35 – 6
278–27114–00	28 – 11
371–27114–00	30 – 12
4GL–27114–00	30 – 3
BLW–27211–00	38 – 15
4BP–27222–02	39 – 6
BLW–27311–00	37 – 3
5VX–27315–00	37 – 11
1WS–27321–00	37 – 16
BLW–27413–00	37 – 22
	38 – 9
BLW–2741L–00	37 – 42
BLW–2742L–00	38 – 26
B7N–27431–00	37 – 41
4BP–27434–01	37 – 32
	38 – 17
5VX–27437–00	37 – 45
	38 – 29
B7N–27441–00	38 – 25
BLW–27442–00	37 – 24
BLW–27443–00	38 – 11
BLW–27445–00	37 – 26
BLW–27446–00	38 – 13
BMG–27451–00	37 – 18
BLW–27453–00	37 – 38
BMG–27461–00	38 – 5
BLW–27463–00	38 – 22
BLW–27498–00	37 – 25
BLW–27499–00	38 – 12
BLW–274A3–00	37 – 1
B34–274A4–00	38 – 1
BAT–28100–00	30 – 25
2H7–28151–00	30 – 22
137–28152–00	30 – 23
23P–28164–00	30 – 24
BLW–2817K–00	29 – 45
4KG–28186–11	30 – 26
BLW–28199–E0	30 – 27
BLW–28199–F0	30 – 27
BLW–28199–G0	30 – 27
BLW–28199–H0	30 – 27
BLW–28199–S0	30 – 27
BLW–2836K–00	29 – 27
BLW–2836L–00	29 – 30
BLW–2838E–00–P0	44 – 17
BLW–2838E–00–P1	44 – 17
BLW–2838E–00–P2	44 – 17
1WS–81315–00	48 – 16
BLW–81410–00	40 – 1
BLW–81450–00	40 – 2
18P–81801–00	41 – 6
1WS–81815–00	41 – 7
18P–81826–00	41 – 5
4XV–8182A–00	41 – 4
	41 – 9
4B5–81844–00	41 – 2
1FK–81847–00	41 – 3
4B5–81871–00	41 – 8
1WS–81890–00	41 – 1
1WS–81916–00	47 – 19
B7N–81940–00	47 – 3
1TP–81950–00	47 – 24
5VK–81950–53	47 – 22
5EA–81952–00	47 – 25
BLW–81952–00	48 – 26
BME–81963–01	47 – 21
5TJ–82100–02	47 – 1
5SL–82113–01	48 – 4
5SL–82119–10	47 – 4

PART NO.	REF. NO.
BLW–8212B–00	22 – 4
133–82131–00	48 – 23
3L8–82131–01	47 – 2
1CB–82151–00	47 – 12
1CB–82151–10	47 – 7
BMG–82151–30	47 – 8
BMG–82151–60	47 – 10
BMG–82151–90	47 – 9
BMG–82151–B0	47 – 11
BLW–82309–00	48 – 17
BME–82310–00	48 – 8
1WS–82380–00	48 – 6
1WS–8246B–00	47 – 23
BME–8246B–00	46 – 16
BME–8249A–00	46 – 19
1WS–82504–01	48 – 15
BFD–82509–00	48 – 19
5SL–82511–08	48 – 5
BLW–82514–00	48 – 29
BLW–82530–00	39 – 19
5ES–82540–00	48 – 18
BME–8255P–01	48 – 3
1WS–82566–01	37 – 12
BLW–82568–00	29 – 39
5PS–82576–02	47 – 26
BLW–82590–00	47 – 6
1UA–82591–00	47 – 17
1B3–82911–00	46 – 1
BLW–82915–00	48 – 22
3YX–82917–01	46 – 8
BLW–8291L–00	46 – 13
BME–8291R–00	46 – 18
BLW–83220–01	43 – 1
BLW–83220–10	43 – 1
B7N–83321–00	8 – 26
	8 – 29
BEA–83371–00	48 – 35
4XV–83513–00	43 – 4
	44 – 6
BLW–83519–00	43 – 5
BME–83525–00	46 – 14
4P9–83591–00	48 – 13
5EB–83912–03	46 – 2
5JJ–83913–00	46 – 11
5VS–83922–00	36 – 9
4XV–83929–00	46 – 7
2C0–83945–00	46 – 3
5LV–83951–00	46 – 6
1HP–83980–03	36 – 12
2PW–84192–00	44 – 3
BME–84300–00	44 – 1
BLW–84301–00	44 – 8
BLW–84302–00	44 – 13
4B4–84334–00	22 – 11
BLW–84369–00	44 – 25
BLW–84700–00	45 – 1
2PN–84745–02	45 – 7
5SL–84753–00	23 – 17
BLW–85112–00	48 – 40
BLW–85122–00	48 – 41
3Y6–85130–02	48 – 37
59C–85131–00	48 – 39
BME–85490–00	44 – 2
BLW–85752–00	28 – 21
B7M–85885–01	12 – 6
5YU–85886–00	28 – 14
2HC–85899–10	48 – 9
BMG–85903–20	48 – 30
BLW–8591A–00	48 – 2
B4T–8592A–00	13 – 4
BLW–85930–07	49 – 1
BLW–85970–01	49 – 5
BLW–85980–00	49 – 9
BG4–86120–00	28 – 37
B34–F3441–10	26 – 10
BW3–F4170–00	28 – 41
1WD–F4780–00	30 – 15
D66–F6280–00	35 – 10
D66–F6290–00	35 – 11
BLW–F8199–D0	30 – 27
BLW–F8199–M0	30 – 27
BLW–F8199–P0	30 – 27
B5Y–H330A–00	42 – 2
BEA–H330A–00	42 – 4
B1X–H330B–00	42 – 3
B5Y–H330B–00	42 – 1
2DP–H4347–00	45 – 8
BGM–H592A–10	13 – 5
BVA–W000B–00	2 – 21
	26 – 12
BLW–W001A–00	1 – 6
	2 – 26
	33 – 36
BLW–W001G–00	2 – 1
	17 – 28
BEB–W001M–00	2 – 10
BEB–W001M–00	17 – 29
BBV–W003B–00	2 – 13
	27 – 41
1WS–W1218–10	6 – 5
2TV–W2470–00	30 – 19
BLW–W8250–01	48 – 1
90101–10034	37 – 4
90101–12079	24 – 21
90105–05024	3 – 19
90105–06027	3 – 5
90105–06048	48 – 36
90105–06148	39 – 28
90105–06169	28 – 16
90105–06226	22 – 22
90105–07006	6 – 3
	6 – 7
90105–08021	23 – 10
	23 – 27
90105–08164	13 – 9
90105–10212	25 – 5
90105–10219	21 – 3
90105–10349	21 – 4
90105–10440	32 – 16
	32 – 28
90105–10445	4 – 21
90105–10498	24 – 12
	25 – 2
90105–12032	4 – 11
90105–12092	21 – 7
90109–05022	23 – 3
	23 – 8
	23 – 20
	23 – 25
90109–06043	21 – 18
90109–06100	14 – 16
90109–06172	21 – 19
	48 – 27
90109–06183	48 – 25
	48 – 28
90109–06202	22 – 5
90109–06259	23 – 2
	23 – 19
90109–06293	3 – 10
90109–06295	6 – 19
90109–06346	24 – 31
	37 – 39
	38 – 23
90109–063F1	48 – 24
90109–064G6	32 – 2
90109–066F0	3 – 21
90109–08045	34 – 2
90109–08233	37 – 23
	38 – 10
90110–05011	48 – 12
90110–05071	37 – 14
90110–05112	28 – 26
90110–06081	3 – 13
90110–06087	29 – 6
	29 – 16
90110–06152	7 – 8
90110–06163	8 – 22
90110–06168	9 – 5
90110–06173	9 – 10
90110–06223	40 – 3
90110–06295	7 – 33
90110–06388	15 – 9
	15 – 15
90110–06389	15 – 10
	15 – 18
90110–06395	14 – 20
90110–06396	6 – 16
	15 – 13
90110–08111	21 – 12
	37 – 48
	38 – 32
90110–08220	37 – 37
	38 – 21
90110–10044	21 – 11
90111–05002	44 – 11
	44 – 16
90111–05021	44 – 18
	44 – 26
90111–05034	44 – 12
90111–06029	30 – 14
90111–06089	22 – 21
90111–06101	35 – 8
90111–06117	30 – 8
90111–06137	45 – 2
90111–06155	30 – 7
90111–06156	43 – 7
90111–06191	8 – 27
	8 – 30
	22 – 2
90111–06194	13 – 3
	13 – 12
90111–08094	48 – 21
90111–10058	37 – 17
90111–10060	37 – 2
	38 – 2
90116–08087	3 – 8
90116–10048	33 – 14
90119–05020	45 – 9
90119–06267	22 – 6
90119–09018	14 – 10
90119–10056	3 – 12
90149–05029	32 – 4
	34 – 4
90149–06030	30 – 21
90149–06109	40 – 4
90149–06158	19 – 7
90149–06189	18 – 16
90149–08030	16 – 3
90159–05065	29 – 41
90160–05012	29 – 36
90160–05013	11 – 14
90160–05014	29 – 2
	29 – 12
90160–05017	43 – 2
90170–06026	37 – 35
90170–08010	39 – 7
90179–05523	48 – 33
90179–08410	13 – 7
90179–10024	21 – 5
90179–20022	17 – 21
90179–22019	2 – 29
	33 – 35
90179–25004	26 – 3
90183–05042	8 – 33
	23 – 4
	23 – 21
	29 – 22
	29 – 25
	29 – 34
	44 – 9
	44 – 14
	44 – 22
	45 – 5
90183–05076	43 – 6
	43 – 11
	44 – 21
	45 – 12
90183–060A6	21 – 20
90185–10011	24 – 15
	25 – 3
90185–10012	37 – 8
90185–16002	24 – 10
90185–18009	33 – 28
90201–04030	47 – 28
90201–05036	29 – 35
	43 – 3
90201–06029	43 – 8
90201–064K6	11 – 24
90201–08053	37 – 33
	38 – 19
90201–08070	39 – 9
90201–10029	17 – 25
90201–10035	21 – 6
90201–10075	37 – 7
90201–101J1	37 – 5
90201–12008	4 – 12
90201–12051	37 – 30
	38 – 18
90201–12575	20 – 12
90201–12790	48 – 20
90201–13020	21 – 8
90201–164H4	24 – 9
90201–177G4	20 – 8
90201–18021	33 – 29
90201–20008	18 – 40
90201–20030	17 – 19
90201–22018	26 – 6
90202–05088	29 – 3
	29 – 13
90202–26142	26 – 4
90206–12074	37 – 31
	38 – 16
90208–20001	17 – 20
90208–22002	2 – 28
	33 – 34
90209–21332	18 – 4
	18 – 8
90209–21351	18 – 12
90209–22352	18 – 11
90209–28008	18 – 24
	18 – 28
	18 – 35
90214–28002	18 – 32
90214–29002	18 – 31
90240–08005	39 – 8
90240–08063	37 – 46
	38 – 30
90269–06001	23 – 16

PART NO.	REF. NO.
90269–06001	29 – 10
	29 – 20
90269–06008	8 – 20
	23 – 7
	23 – 24
	29 – 43
90269–06019	29 – 29
	29 – 32
90269–07007	24 – 29
	24 – 32
90269–07008	22 – 24
90269–07077	21 – 25
90269–07923	29 – 9
	29 – 19
90269–08008	37 – 40
	38 – 24
90280–05029	4 – 10
90282–04036	4 – 20
90338–06018	23 – 5
	23 – 22
90338–14008	22 – 13
90340–14132	10 – 6
90340–18002	3 – 6
90340–36008	15 – 3
90380–16158	24 – 7
90387–05028	39 – 15
90387–05042	45 – 10
90387–06024	8 – 21
90387–060A7	22 – 7
90387–06159	43 – 10
	43 – 14
90387–06161	44 – 4
90387–06170	24 – 27
90387–06173	21 – 17
90387–06263	8 – 7
90387–06287	28 – 13
90387–06289	49 – 3
90387–062M9	28 – 39
90387–06300	11 – 22
90387–06372	22 – 20
90387–06554	28 – 8
90387–067V1	45 – 3
90387–07391	30 – 5
90387–07717	22 – 3
90387–10020	37 – 6
90387–10107	29 – 5
	29 – 15
90387–1012A	24 – 18
90387–1012A	25 – 4
90387–10132	24 – 13
90387–17021	31 – 9
90387–17530	31 – 8
90387–20035	33 – 19
90387–20036	33 – 18
90387–21003	18 – 10
90387–25008	18 – 39
90387–25043	18 – 3
90387–28004	18 – 30
	18 – 34
90387–30012	18 – 19
90387–31003	18 – 23
90401–10020	39 – 30
90401–10042	36 – 20
90401–10172	36 – 19
	39 – 32
90413–06031	12 – 10
90430–06014	7 – 5
90430–08143	15 – 6
90430–10004	48 – 14
90430–10005	36 – 21
	39 – 31
	39 – 33
90445–10064	8 – 23
90445–10069	28 – 42
90445–197J2	37 – 10
90450–35001	7 – 12
	8 – 12
90450–56011	11 – 2
	11 – 17
90450–56012	11 – 3
	11 – 16
90462–08102	14 – 17
90464–04005	23 – 12
	23 – 14
	23 – 29
	23 – 31
90464–07009	39 – 29
90464–07014	39 – 27
90464–07M40	8 – 24
90464–10233	49 – 11
90464–12013	49 – 8
90464–13073	35 – 9
90464–14010	47 – 15
	47 – 20
	49 – 7
90464–16001	39 – 35
90464–16001	47 – 30
90464–16061	22 – 10
90464–17003	47 – 29
90464–17008	39 – 24
90464–18002	36 – 26
90464–18004	47 – 31
90464–20191	47 – 14
90464–30009	49 – 12
90464–36005	48 – 34
90464–65001	47 – 18
90464–80002	47 – 16
90465–10098	46 – 12
90467–090A2	12 – 11
	28 – 31
	28 – 33
	28 – 35
	28 – 43
90467–11044	39 – 17
90467–13083	11 – 19
90467–160A2	11 – 27
90467–170A6	7 – 21
	7 – 23
90467–17128	11 – 26
90467–290A0	7 – 11
	7 – 13
	8 – 11
90480–01558	28 – 2
	48 – 32
90480–01559	21 – 13
	22 – 9
	29 – 23
	29 – 26
90480–09003	22 – 12
90480–10003	44 – 7
90480–10016	45 – 6
90480–11009	45 – 11
90480–12314	43 – 9
	43 – 13
90480–13001	45 – 4
90480–13010	9 – 8
90480–14003	22 – 8
90480–14229	49 – 2
90480–14604	30 – 4
90480–15001	11 – 20
90480–15014	11 – 21
90480–15363	8 – 6
90480–16003	28 – 12
90480–17007	29 – 4
90480–17007	29 – 14
90501–12743	37 – 43
	38 – 27
90501–22721	4 – 17
90506–18021	20 – 1
90506–23008	38 – 20
90506–26014	37 – 9
90508–18132	17 – 24
90508–18135	37 – 21
	38 – 8
90508–29040	20 – 5
90520–02013	28 – 46
90520–02826	28 – 47
90520–10023	44 – 19
	44 – 24
90520–20022	21 – 14
90560–08326	23 – 11
	23 – 28
91312–05010	28 – 24
	28 – 27
91312–05020	48 – 7
91312–06025	41 – 10
91312–06030	10 – 9
91314–06014	7 – 7
91314–08030	26 – 11
	27 – 39
91314–08040	27 – 18
91314–08045	26 – 9
91317–06020	20 – 15
91317–06035	35 – 5
91380–06016	47 – 13
91401–20012	39 – 10
91402–25015	37 – 20
	37 – 47
	38 – 7
	38 – 31
91701–08040	37 – 19
	38 – 6
91808–16023	3 – 3
	3 – 4
92012–06010	21 – 23
	39 – 34
92012–06016	21 – 27
	21 – 31
	49 – 15
92012–06020	24 – 28
92012–06045	49 – 14
92014–06014	49 – 10
92017–06010	24 – 34
	28 – 45
92017–06012	28 – 17
	36 – 25
92017–06016	49 – 6
92017–08012	15 – 5
92017–08016	37 – 27
92017–08030	38 – 14
92902–04100	36 – 14
92902–04600	36 – 15
92902–08600	33 – 26
92902–10200	24 – 14
92907–05600	37 – 13
92907–08600	7 – 36
93102–12106	20 – 11
93102–15212	7 – 40
93102–25017	31 – 4
93102–28022	33 – 3
93102–40030	18 – 21
93106–22019	24 – 4
93106–40041	33 – 12
93108–35004	24 – 6
93109–17071	24 – 17
	24 – 24
93210–04092	14 – 3
93210–07540	14 – 12
93210–12790	14 – 6
93210–16325	14 – 9
93210–17008	48 – 10
93210–207A0	9 – 7
93210–235A1	7 – 2
	7 – 6
93210–27194	15 – 20
93210–33006	7 – 15
93210–357A3	15 – 4
93306–00106	7 – 26
93306–00449	33 – 4
93306–20357	31 – 3
93306–20464	18 – 14
	18 – 41
93306–20488	33 – 2
93306–20663	18 – 18
93306–20666	33 – 10
93310–332C2	17 – 17
93315–21570	7 – 39
93315–31758	24 – 16
93317–11096	7 – 38
93317–11295	20 – 10
93317–22262	24 – 3
93317–31771	24 – 23
93399–99931	2 – 24
	26 – 1
93399–99932	2 – 22
	27 – 38
93440–25186	18 – 5
	18 – 7
93440–31187	18 – 25
	18 – 27
	18 – 36
93440–64199	18 – 20
93450–19052	4 – 9
93501–04011	3 – 7
	37 – 44
	38 – 28
93603–12007	7 – 32
93605–10090	4 – 18
93900–00030	31 – 6
	33 – 7
94112–17151	31 – 5
94118–17095	33 – 6
94581–79060	9 – 4
94591–61134	6 – 11
94682–64021	2 – 32
	33 – 21
94701–00436	1 – 1
	3 – 9
94A40–24108	2 – 31
	33 – 20
95022–06008	47 – 5
95022–06010	7 – 4
	38 – 4
95027–06010	21 – 29
95027–06012	39 – 21
95027–06014	21 – 16
	21 – 21
95027–06020	46 – 5
95027–06025	36 – 23
95302–08600	33 – 25
95314–06700	37 – 36
95602–05200	37 – 15
	48 – 38
95602–10200	25 – 6
	33 – 15
95602–12200	24 – 22
95607–06200	46 – 4
95617–06100	36 – 8

PART NO.	REF. NO.
95702–05500	48 – 42
95702–06500	30 – 17
95707–05500	39 – 23
95707–06500	28 – 38
95812–06020	7 – 16
95812–06030	28 – 9
95812–06040	9 – 3
	14 – 14
95812–06060	14 – 15
95812–08065	14 – 13
95817–06020	7 – 19
	49 – 4
95817–06025	11 – 23
95822–06020	44 – 5
95D32–06020	30 – 10
95D32–06025	8 – 8
95D34–06016	13 – 10
95D37–06025	43 – 12
97702–40025	47 – 27
97702–50016	23 – 9
	23 – 26
97702–60520	48 – 31
97707–50012	29 – 7
	29 – 17
	29 – 28
	29 – 31
	44 – 10
	44 – 15
	44 – 23
97707–50016	8 – 32
	23 – 33
98502–04012	36 – 13
98502–05012	28 – 15
98507–04010	46 – 10
98507–04016	46 – 15
98507–04018	46 – 17
	46 – 20
98704–03020	46 – 9
99001–07600	7 – 37
99002–10600	20 – 13
99009–10400	17 – 26
99009–12400	7 – 29
99009–15500	9 – 2
99009–17400	20 – 9
99244–00080	22 – 25
99247–00080	22 – 25
99480–03014	15 – 2
99530–08012	15 – 8
99530–08012	15 – 14
99530–10014	14 – 4
99530–10114	3 – 15